

# OKI

---

## C5300/C5100 Color LED Page Printer MAINTENANCE MANUAL

ODA/OEL/INT

2003-09-03 Rev.3

## Document Revision History

Rev.No.	Date	Corrected items			Person in charge
		No.	Page	Description of change	
0.5	2002-12-26			ISSUE	NC1 Maekawa
1	2003-03-28		All	Add C5300	NC1 Maekawa
2	2003-06-20			Substantial change	ME4 Enomoto
3	2003-09-03			Add C5300VE	CN12 li

# PREFACE

This manual describes the procedures of the maintenance of the C5300/C5100 printers.

The document is produced for maintenance personnel use. For details on the procedures for handling the C5300/C5100 of printers, see its user documentation.

- Note!**
- The descriptions in this manual are subject to change without prior notice.
  - In preparing the document, efforts have been made to ensure that the information in it is accurate. However, errors may be crept into the document. Oki Data assumes no responsibility for any damage resulting from, or claimed to be the results of, those repairs, adjustments or modifications to the printers which are made by users using the manual.
  - The parts used for the printers are sensitive and, if handled improperly, may be damaged. It is strongly recommended that the products are maintained by maintenance men registered with Oki Data.

# CONTENTS

<b>1. SPECIFICATIONS .....</b>	<b>6</b>
1.1 System Configuration .....	6
1.2 Printer Configuration .....	8
1.3 Option Configuration .....	10
1.4 Specifications .....	11
<b>2. PARTS REPLACEMENT .....</b>	<b>13</b>
2.1 Precautions in Replacing Parts .....	13
2.2 Part Replacement Procedures .....	15
2.2.1 Top Cover .....	15
2.2.2 Left Side Cover .....	16
2.2.3 Right Side Cover .....	17
2.2.4 Face-Up Tray .....	18
2.2.5 Rear Cover .....	19
2.2.6 LED Assy / LED Assy Springs .....	20
2.2.7 Controller PWB .....	21
2.2.8 Print Engine Controller PWB .....	23
2.2.9 Top Cover Unit. ....	26
2.2.10 Controller Panel Assy .....	27
2.2.11 Board RSP / Environment Sensor / Top Cover Handle .....	28
2.2.12 Low Voltage Power Unit / FAN (ID) / FAN (PowL) / Hopping Motor / Fuser Motor	29
2.2.13 Board-PRD .....	30
2.2.14 Guide - Eject Assy / Color Registration Assy / Board-RSM .....	31
2.2.15 FAN (Fuser) / Belt Motor / High Voltage Power Supply Board / Cover Open Switch / Image Drum Up/Down Sensor .....	33
2.2.16 Multipurpose Tray (MPT) Assy .....	34
2.2.17 Feeder Unit / Board-RSF / Multipurpose Tray (MPT) Hopping Roller / Multipurpose Tray (MPT) Frame Separator / Cover-Front .....	35
2.2.18 Main Motors / Solenoid / Paper-End Sensor .....	36
2.2.19 Feed Roller .....	38
2.2.20 Shaft Eject Assy (FU) / Shaft Eject Assy (FD) / Eject Sensor .....	39
2.2.21 Fuser Unit .....	40
2.2.22 Belt Unit .....	41
<b>3. ADJUSTMENTS .....</b>	<b>42</b>
3.0.1 System Maintenance Menu .....	42
3.0.2 Maintenance Utility .....	44
3.1 Maintenance Modes and Their Functions .....	45
3.1.1 Maintenance Menu .....	45
3.1.2 Engine Maintenance Mode .....	46
3.1.2.1 Operator panel .....	46
3.1.2.2 Normal self-diagnostic mode (level 1) .....	46
3.1.2.2.1 Entering self-diagnostic mode (level 1) .....	47
3.1.2.2.2 Exiting self-diagnostic mode .....	47
3.1.2.3 Switch scan test .....	47
3.1.2.4 Motor and clutch test .....	50
3.1.2.5 Test printing .....	52
3.1.2.6 Consumable counter display .....	57
3.1.2.7 Consumable counter display - continuous .....	57
3.1.2.8 Operator panel display .....	58
3.1.2.9 Color registration adjustment test .....	63
3.1.2.10 Print density adjustment test .....	63
3.1.3 Printing on Controller-Equipped Printer on a Standalone Basis .....	64
3.1.4 Switch Press Functions at Printer Power-On .....	65
3.2 Adjustments after Parts Replacement .....	66

3.2.1	Precautions in replacing engine controller board .....	67
3.2.2	EEPROM Setting after ARC Board / OWL Board / SPA Board Replacement .....	68
3.2.3	Destination Setting (Check Method: Printing demo page) .....	69
3.3	Print Density Adjustment .....	69
3.4	Print Density Adjustment (Calibration Chip) .....	70
<b>4.</b>	<b>REGULAR MAINTENANCE .....</b>	<b>71</b>
4.1	Parts Replaced Regularly .....	71
4.2	Cleaning .....	71
4.3	Cleaning the LED Lens Array .....	71
4.4	Cleaning the Pick-up Roller .....	71
<b>5.</b>	<b>TROUBLESHOOTING PROCEDURES .....</b>	<b>72</b>
5.1	Precautions before troubleshooting .....	72
5.2	Precautions before handling an abnormal image .....	72
5.3	Precautions upon handling an abnormal image .....	72
5.4	Preparing for Troubleshooting .....	73
5.5	Troubleshooting Procedure .....	73
5.5.1	LCD message list .....	74
5.5.2	Preparing for troubleshooting .....	84
5.5.3	Image Problem Troubleshooting .....	95
5.5.4	Actions Taken after Forced HDD/Flash Initialization .....	108
5.6	Fuse Checking .....	109
<b>6.</b>	<b>CONNECTION DIAGRAM .....</b>	<b>110</b>
6.1	Resistance Checks .....	110
6.2	Program/Font ROM Layouts .....	114
<b>7.</b>	<b>PARTS LIST .....</b>	<b>121</b>
<b>APPENDIX A</b>	<b>INTERFACE SPECIFICATIONS .....</b>	<b>147</b>
1.	Parallel Interface Specifications (C5300) .....	147
1.1	Parallel Interface .....	147
1.2	Parallel Interface Connector and Cable .....	147
1.3	Parallel Interface Level .....	147
1.4	Timing Charts .....	148
1.5	Parallel I/F Signals .....	149
2.	Universal Serial Bus (USB) Interface Specifications .....	150
2.1	USB Interface .....	150
2.2	USB Interface Connector and Cable .....	150
2.3	USB Interface Signals .....	150
3.	Network Interface Specifications .....	151
3.1	Network Interface .....	151
3.2	Network Interface Connector and Cable .....	151
3.3	Network Interface Signals .....	151
<b>APPENDIX B</b>	<b>2ND TRAY MAINTENANCE .....</b>	<b>152</b>
1.	Parts Replacement .....	152
1.1	PCB .....	152
1.2	Frame Assy- Hopping .....	153
2.	PARTS LIST .....	154
<b>APPENDIX C</b>	<b>DUPLEX UNIT MAINTENANCE .....</b>	<b>156</b>
1.	Parts Replacement .....	156
1.1	Duplex Unit .....	156
1.2	Upper Assy / Rear Assy .....	157
1.3	Duplex Transport Assy .....	158
2.	PARTS LIST .....	160

# 1. SPECIFICATIONS

## 1.1 System Configuration

### C5300

Figure 1-1-1 shows the system configuration of C5300.




Figure 1-1-1

C5100

Figure 1-1-2 shows the system configuration of C5100.




Figure 1-1-2

## 1.2 Printer Configuration

The inside of C5300 printers is composed of the following:

- Electrophotographic Processor
- Paper Paths
- Controller Block (CU and PU)
- Operator Panel
- Power Units (High Voltage Unit and Low Voltage Unit)

Figure 1-2-1 shows the configuration of each printer.




Figure 1-2-1

The inside of C5100 printers is composed of the following:

- Electrophotographic Processor
- Paper Paths
- Controller Block (CU and PU)
- Operator Panel
- Power Units (High Voltage Unit and Low Voltage Unit)

Figure 1-2-2 shows the configuration of each printer.





Figure 1-2-2


### 1.3 Option Configuration

The following options are available for C5300/C5100.


(1) 2nd Tray




(2) Duplex Unit




(3) Expansion Memory (C5300) 64 MB



(4) Expansion Memory (C5100) 64/256 MB



(5) Hard Disk (C5300)



## 1.4 Specifications

- (1) External Dimensions  
Height: 345 mm. Width: 422 mm. Length: 561 mm.
- (2) Weight  
Approx. 20 kg (except consumables)
- (3) Paper  
Type: Plain paper, Transparencies (Recommended: MLOHP01)  
Size: Postal card, Legal 13" or 14", Executive, A4, A5, B5, A6 (A6 held in and fed from only 1st tray and front feeder)  
Weight: 1st tray 55 kg to 103 kg (64 to 120 g/m<sup>2</sup>)  
Front feeder 55 kg to 172 kg (64 to 203 g/ m<sup>2</sup>)
- (4) Print Speed  
Color: 12 pages per minute (Transparencies: 6 pages per minute)  
Monochrome: 20 pages per minute (Transparencies: 12 pages per minute)  
Postal Cards, Labels, Thick Paper: 8 pages per minute
- (5) Resolution  
600 × 1200 dots per inch
- (6) Power Input  
100 VAC ±10%
- (7) Power Consumption  
Peak: 850W  
Normal Operating: 400W (5% duty)  
Idle: 80W  
Power Save Mode: 18W or less
- (8) Frequency  
50Hz or 60Hz ± 2 Hz
- (9) Noise  
Operating: 54 dB (Without duplex unit and 2nd tray)  
Standby: 40 dB  
Power Saving: Background noise
- (10) Consumable Life  
Toner Cartridges: 5,000 pages (images) (5% duty, Each of Y, M, C and K)  
Image Drums: 22,000 pages (images) (5% duty, Continuous printing, Each of Y, M, C and K)
- (11) Parts Replaced Periodically  
Fuser Unit: Every 45,000 pages (prints)  
Belt Unit: Equivalent of 50,000 pages (images) (3 pages/job)

## (12) Temperature and Relative Humidity

## Temperatures

## Temperature condition

	Celsius	Remarks
Operating	10 to 32	17 to 27 Celsius (Temperatures to assure full color print quality)
Non-Operating	0 to 43	Power off
Storage (Max. One Year)	-10 to 43	With drum and toner
Delivery (Max. One Month)	-29 to 50	With drum and without toner
Delivery (Max. One Month)	-29 to 50	With drum and toner

## Humidities

## Humidity condition

	Relative Humidity (%)	Max. Wet-Bulb Temperature (Celsius)	Remarks
Operating	20 to 80	25	50 to 70% (for assurance of full color print quality)
Non-Operating	10 to 90	26.8	Power off
Storage	10 to 90	35	
Delivery	10 to 90	40	

## (13) Printer Life

420,000 pages (on a A4-size basis) or five years

## 2. PARTS REPLACEMENT

This section describes the procedure for replacing the parts, assemblies and units in the field. The replacing procedure is given for detachment. To attach, use the reverse procedure.

### 2.1 Precautions in Replacing Parts


(1) Before replacing the parts, be sure to remove the AC cable and the interface cable.

(a) To remove the AC cable, always use the following procedure.

- i) Flip the power switch of the printer off (to "O").
- ii) Pull the AC inlet plug of the AC cable out of the AC receptacle.
- iii) Remove the AC cable and the interface cable from the printer.

(b) To connect the printer again, always use the following procedure.

- i) Connect the AC cable and the interface cable to the printer.
- ii) Insert the AC inlet plug into the AC receptacle.
- iii) Flip the power switch of the printer on (to "I").



(2) Do not disassemble the printer so long as it operates properly.

(3) Minimize the disassembly. Do not detach parts other than those shown in the replacing procedure.

(4) For maintenance, use designated tools.

(5) Follow the order instructed to disassemble the printer. Incorrect order may damage the parts.

(6) Small parts such as screws and collars tend to get lost, so temporarily place and fix them in their original positions.






(7) When handling ICs and circuit boards such as microprocessors, ROMs and RAMs, do not use gloves that likely to have static.

(8) Do not place the printed circuit boards directly on the printer or the floor.

## [Maintenance Tools]

Table 2-1 lists tools necessary to replace the printed circuit boards and the units.

Table 2-1 Maintenance Tools

No.	Service Tools	Q' ty	Place of use	Remarks
1	 No. 1-100 Philips screwdriver	1	2~2.5 mm screws	
2	 No. 2-200 Philips screwdriver, Magnetized	1	3~5 mm screws	
3	 No. 3-100 screwdriver	1		
4	 No. 5-200 screwdriver	1		
5	 Digital multimeter	1		
6	 Pliers	1		
7	 Handy cleaner	1		
8	 LED Head cleaner P/N 4PB4083-2248P001	1	Cleans LED head	
9	 High voltage probe	1		

## 2.2 Part Replacement Procedures

This section describes the procedures for replacing the parts and assemblies shown in the following disassembly chart:

### 2.2.1 Top Cover

- (1) Open the top cover assy.
- (2) Remove the ten screws (black) ① to detach the cable cover ② and the top cover ③.




Figure 2-2-1 Top Cover

### 2.2.2 Left Side Cover

- (1) Open the top cover ①.
- (2) Open the feeder unit ②.
- (3) Remove the screw (gold) ③ to detach the left side cover ④.




Figure 2-2-2 Left Side Cover

### 2.2.3 Right Side Cover

- (1) Open the top cover ①.
- (2) Open the feeder unit ②.
- (3) Loosen the screw ③ to detach the right side cover ④.




Figure 2-2-3 Right Side Cover

## 2.2.4 Face-Up Tray

- (1) Open the face-up tray ① in the direction of the arrow, and disengage it at its two places to detach it.




Figure 2-2-4 Face-Up Tray

## 2.2.5 Rear Cover

- (1) Remove the face-up tray (see section 2.2.4).
- (2) Remove the two screws (gold) ①.
- (3) Insert a flat-blade driver into the hole A to disengage the claw A, at each of the two places, and pull in an arc the rear cover ② in the direction of the allow A.
- (4) Push the lower part of the rear cover ② in the direction of the allow B to disengage the three claws B, then detach the rear-cover ② in the direction of the allow C.




Figure 2-2-5 Rear Cover

## 2.2.6 LED Assy / LED Assy Springs

- (1) Open the top cover ①.
- (2) Remove the cable connection of, and disengage the two hooks of, the LED assy ② to detach the assy (the two springs ③ become detached together with the LED Assy ②).




Figure 2-2-6 LED Assy / LED Assy Springs

## 2.2.7 Controller PWB

## C5300

- (1) Remove the Print Engine Controller PWB (see section 2.2.8).
- (2) Remove the screw ① and then the head cable ②.
- (3) Remove the eight screws (gold) ③, then detach the controller PWB ④.




Figure 2-2-7-1 Controller PWB (C5300)

## C5100

- (1) Open the top cover.
- (2) Remove the right side cover (see section 2.2.3).
- (3) Unscrew the three screws (gold) ① to remove the plate-shield assy (GDI) ②.
- (4) Remove the screw (gold) ③ and then the head cable ④.
- (5) Remove the six screws (gold) ⑤ and the connector ⑥, then detach the controller PWB ⑦.




Figure 2-2-7-2 Controller PWB (C5100)

## 2.2.8 Print Engine Controller PWB

## C5300

- (1) Open the top cover.
- (2) Remove the right side cover (see section 2.2.3).
- (3) Remove the connector ①, and disengage the two hooks ② of to detach the FAN (CU) ③.
- (4) Remove the three screws (gold) ④ to detach the plate shield assy (PCL) ⑤.
- (5) Remove the three screws (gold) ⑥ and all the connectors to detach the print engine controller PWB ⑦.




Figure 2-2-8-1 Print Engine Controller PWB (C5300)

## C5100

- (1) Remove the plate shield assy (GDI) [see section 2.2.7, steps (1) to (3)].
- (2) Remove the three screws (gold) ① and all the connectors to detach the print engine controller PWB ②.




Figure 2-2-8-2 Print Engine Controller PWB (C5100)




Figure 2-2-8-3 Print Engine Controller Board Cable Route

### 2.2.9 Top Cover Unit.

- (1) Remove the top cover (see section 2.2.1).
- (2) Remove the left side cover (see section 2.2.2).
- (3) Remove the right side cover (see section 2.2.3).
- (4) Remove the rear side cover (see section 2.2.5).
- (5) Remove the plate-shield assy (GDI) [see section 2.2.7, step (2)].
- (6) Remove the two E-shaped rings ① and the two springs - torsion ②, then detach the top cover unit ③.




Figure 2-2-9 Top Cover Unit

### 2.2.10 Controller Panel Assy

- (1) Open the top cover.
- (2) Open the feeder unit.
- (3) Remove the right side cover (see section 2.2.3).
- (4) Remove the plate-shield Assy (GDI) [see section 2.2.7, step (2)].
- (5) Make control panel Assy connector removal (see section 2.2.8).
- (6) Remove the four screws (gold) ①, then detach the control panel Assy ②.




Figure 2-2-10 Control Panel Assy

### 2.2.11 Board RSP / Environment Sensor / Top Cover Handle

- (1) Remove the control panel assy (see section 2.2.10).
- (2) Disengage the two claws A of the lever-lock ② to remove the frame OP ①, and remove the lever-lock ② and the spring-compression ③.
- (3) Disengage the two claws B of the cover assy OP ④ to remove it, and remove the springs torsion ⑤.
- (4) Detach the board RSP ⑥, the environment sensor ⑦, the cable ⑧ and the harness ⑨.




Figure 2-2-11 Board RSP / Environment Sensor / Top Cover Handle

## 2.2.12 Low Voltage Power Unit / FAN (ID) / FAN (PowL) / Hopping Motor / Fuser Motor

- (1) Remove the print controller PWB (see section 2.2.8).
- (2) Remove the controller PWB (see section 2.2.7).
- (3) Remove the film ① and the frame duct ② to demount the FAN (ID) ③.
- (4) Remove the two screws (gold) ④ and the four connectors to demount the POW unit ⑤.
- (5) Demount the FAN (PowL) ⑥ by releasing claw engagement.
- (6) Remove the two screws (black) ⑦ and the connector to detach the hopping motor ⑧.
- (7) Remove the two screws (black) ⑨ and the connector to detach the fuser motor ⑩.

**Note!** When reassembling the FAN (PowL) ⑥, check the attachment direction.




Figure 2-2-12 Low voltage Power Unit / FAN (ID) / FAN (PowL) / Hopping Motor / Fuser Motor

## 2.2.13 Board-PRD

- (1) Remove the right side cover (see section 2.2.3).
- (2) Remove the print engine controller PWB and the controller PWB (see sections 2.2.7 and 2.2.8).
- (3) Remove the film and the low voltage power unit (see section 2.2.12).
- (4) Remove the three screws (gold) ① and the two E-shaped snaps ② to remove the plate-outer ③.
- (5) Remove the gear-idle-ID - K ④, Y and C ⑤, each in one piece, and M ⑥, and the spring ⑦ of the solenoid.
- (6) Unlatch, and remove by sliding the guide assy - side R ⑧, the assy and detach the board-PRD ⑨ and the nine springs ⑩.

**Note!** When reassembling the board-PRD, do not forget to attach the spring of the solenoid ⑦.




Figure 2-2-13 Board-PRD

## 2.2.14 Guide - Eject Assy / Color Registration Assy / Board-RSM

- (1) Remove the left side cover, the write side cover, the rear cover and the top cover unit (see sections 2.2.2, 2.2.3, 2.2.5 and 2.2.9).
- (2) Remove the engine controller PWB, the controller PWB and the film [see sections 2.2.7 and 2.2.8, and step (3) of section 2.2.12].
- (3) Unscrew the two screws (gold) ① to remove the plate-heat ②.
- (4) Remove the two springs - torsion ③ and disengage the two claws to remove the cover-driver ④.
- (5) Make screw (gold) ⑨ and connector removal to detach the board-RSM ⑩.
- (6) Make two-screw (gold) ⑤ removal to detach the color registration assy ⑥.
- (7) Make two-screw (gold) ⑦ removal to detach the guide eject assy ⑧.




Figure 2-2-14-1 Guide - Eject Assy / Color Registration Assy / Board-RSM




Figure 2-2-14-2 Board-RSM Cable Route

### 2.2.15 FAN (Fuser) / Belt Motor / High Voltage Power Supply Board / Cover Open Switch / Image Drum Up/Down Sensor

- (1) Remove the left side cover (see section 2.2.2).
- (2) Make screw (gold) ① and connector removal to detach the belt motor ②.
- (3) Remove the screw (gold) ③, disengage the latch and make connector removal to detach the high voltage power supply board ④.
- (4) Remove the two screws (gold) ⑤ to remove the cover-rear ⑥.
- (5) Remove the connector and, turning the FAN (Fuser) ⑦, detach the FAN (Fuser) ⑦.
- (6) Remove the connector and unlatch the cover open switch ⑧ to detach the switch.
- (7) Remove the connector and pull out the lock-piece ⑨ to detach the image drum up/down sensor ⑩.




Figure 2-2-15 FAN (Fuser) / Belt Motor / High Voltage Power Supply Board / Cover Open Switch / Image Drum Up/Down Sensor

## 2.2.16 Multipurpose Tray (MPT) Assy

- (1) Open the MPT assy ①.
- (2) Remove the two stoppers and the two supports to detach the MPT assy ①.




Figure 2-2-16 MPT Assy

### 2.2.17 Feeder Unit / Board-RSF / Multipurpose Tray (MPT) Hopping Roller / Multipurpose Tray (MPT) Frame Separator / Cover-Front

- (1) Open the top cover.
- (2) Remove the left side cover (see section 2.2.3).
- (3) Make plate-shield (GDI) and connector removal (see section 2.2.7).
- (4) Disengage the claws of the stay L ① and the stay R ②, sliding the feeder unit ③, detach the feeder unit.
- (5) Remove the cover sensor ④ by releasing claw engagement.
- (6) Make connector removal to detach the board-RSF ⑤.
- (7) Remove the lever ⑥ by turning it until it is unlocked.
- (8) Remove the two screws (black) ⑦ to remove the stay L ①.
- (9) Remove the four screws (black) ⑧, disengage the front two claws A and remove the feed Assy ⑨.
- (10) Remove the two lock shafts ⑩ and the two springs ⑪ and disengage the four claws to detach the hopping roller assy ⑫.
- (11) Remove the hopping roller shaft ⑬.
- (12) Remove the two supports to detach the MPT frame separator ⑭, and remove the spring ⑮.




Figure 2-2-17 Feeder Unit / Board-RSF / MPT Hopping Roller / MPT Frame Separator / Cover-Front

### 2.2.18 Main Motors / Solenoid / Paper-End Sensor

- (1) Remove the left side cover, the right side cover, the rear side cover, the top cover unit and the feeder unit (see sections 2.2.2 , 2.2.3, 2.2.5, 2.2.9 and 2.2.17).
- (2) Remove the print engine controller PWB, the controller PWB and the film [see sections 2.2.7, 2.2.8 and 2.2.12 (3)].
- (3) Remove the fan (ID), the frame duct, the fan (Pow L) and the low voltage power unit (see section 2.2.12).
- (4) Remove the plate-heat, the eject assy, the cover-driver, the color-registration assy and the board-RSM (see section 2.2.14).
- (5) Unscrew the two screws (gold) ① to remove the plate-driver ②.
- (6) Disengage the latch to remove the cover-hopping ③.
- (7) Remove the fan (fuser) and the image drum up/down sensor ④ (see section 2.2.15).
- (8) Disengage the latch to remove the gear assy - planet ⑤, the shaft ⑥ and the three rollers ⑦.
- (9) Unscrew the two screws (gold) ⑧ to remove the side plate R assy ⑨.
- (10) Remove the three screws (gold) ⑩ and the two E rings ⑪, then remove the plate-outer ⑫, the gear-idle K ⑬, and Y and C ⑭, and M ⑮.
- (11) Remove the three screws (gold) ⑯ to remove the plate-lock-out-ID ⑳ and the plate-inner ㉑.
- (12) Remove the screws (gold) ㉒ (one screws each motor-ID ㉓) and the connectors, then uninstall the motors-ID ㉔.
- (13) Remove the screw (gold) ㉕ and the two screws (black) ㉖ to remove the gear assy - HP ㉗.
- (14) Remove the screw (gold) ㉘ to uninstall the solenoid ㉙.
- (15) Remove the spring ㉚, disengage the claw and remove the bushing ㉛, the hopping roller shaft ㉜ and the frame-hopping ㉝.
- (16) Detach the paper-end sensor ㉞ and the paper-end lever ㉟.




Figure 2-2-18 Main Motors / Solenoid / Paper-End Sensor

### 2.2.19 Feed Roller

- (1) Remove the cassette.
- (2) Unlatch and detach the feed roller ①.




Figure 2-2-19 Feed Roller

## 2.2.20 Shaft Eject Assy (FU) / Shaft Eject Assy (FD) / Eject Sensor

- (1) Detach the eject assy ①.
- (2) Disengage the latch to separate the guide-eject-lower ② and the guide-eject-upper ③.
- (3) Remove the gear-idle-eject ④, then detach the shaft assy - eject (FU) ⑤ and the shaft assy - eject (FD) ⑥.
- (4) Make connector and guide-cable R ⑦ removal.
- (5) Detach the lever - eject sensor ⑧ and then the eject sensor ⑨.




Figure 2-2-20 Shaft Eject Assy (FU) / Shaft Eject Assy (FD) / Eject Sensor

### 2.2.21 Fuser Unit

- (1) Open the top cover ①.
- (2) Rise the fuser unit lock levers (two blue portions) ② in the directions of the arrows to detach the fuser unit ③.




Figure 2-2-21 Fuser Unit

### 2.2.22 Belt Unit

- (1) Open the top cover ①.
- (2) Remove the image drum unit.
- (3) Turn the lock levers (two blue portions) ② in the direction of the arrow (  ) and, grasping the lever (blue) ③, detach the belt unit ④.




Figure 2-2-22 Belt unit

### 3. ADJUSTMENTS

Adjustments of C5300/C5100 printers can be made using maintenance utility software and key input from their operator panels. In addition to a standard menu, there is a maintenance menu in the display of their operator panels. The menu that serves the purpose of intended adjustment is to be selected.

#### 3.0.1 System Maintenance Menu

Turning on printer power while holding the MENU+ and MENU- keys down activates System Maintenance menu. The menu is only displayed in English on a printer to any destination.

**Note!** System Maintenance menu, from which settings such as printer destinations can be changed, is hidden from users' view.

Table 3-0-1 Maintenance Menu Display Table

Category	Item(1st Line)	Value(2nd Line)	DF	Function
OKIUSER	OKIUSER	ODA OEL APS JP1 JPOEM1 OEMA OEML		Sets Brand and Destination. JPOEM1: Japan OEM OEMA: Overseas OEM for A4 default OEML: Overseas OEM for Letter default Boots up automatically when a brand is selected.
MAINTENANCE MENU	HDD FORMAT	EXECUTE		Format for HDD. Process as same as connecting for new HDD.
	FLASH FORMAT	EXECUTE		Format for Resident FLASH. NIC Program is elased.
	MENU RESET	EXECUTE		Sets factory default for EEPROM of CU board.
CONFIG MENU	CODESET	TYPE1 TYPE2	*	TYPE1: Russian/Greek does not appear. TYPE2: Russian/Greek appear. When you select TYPE2, LANGUAGE selections in SYS CONFIG MENU in USER MENU display RUSSIAN and GREEK. (The value change is enabled after rebooting.)
ENG STATUS PRINT	ENG STATUS PRINT	EXECUTE		Selecting by the ENTER key, then pressing the On-line switch will prompt initialization and printing Engine information.
TEST PRINT MENU (C5300)	TEST PRINT MENU	ENABLE DISABLE	*	Switches ENABLE and DISABLE to display the TEST PRINT MENU category in the User Menu.
PAGE CNT PRINT	PAGE CNT PRINT	ENABLE DISABLE	*	Sets printing or not printing the total page count in PRINT MENU MAP.
FUSE KEEP MODE	FUSE KEEP MODE	EXECUTE		When ENTER key is pressed, CU issues a command to PU, and the printer becomes ON LINE. With the power on, replace the consumables with new ones and check the printer behavior. (At this point, fuse of new consumables is not cut, and operation count will not be added to the value of old consumables.) When the power is turned off, the printer exits check mode, and it becomes disabled when you turn on the power.

Category	Item(1st Line)	Value(2nd Line)	DF	Function
PERSONALITY (C5300)	PCL	ENABLE DISABLE	*	Changes the default PDL language for each brand. PDLs that are disabled in this menu will not be displayed on User Menu's or Admin Menu's PERSONALITY. When print data in the PDL language set to DISABLE is received, the printer will display INVALID DATA and discard received data. (HP-GL/2 is under development, and there is no plan to implement as yet in the product.) PX715: Cannot disable PS3 (PostScript). Same as PX711/713.(Only menu is implemented for future expansion.) When PCL is set to DISABLE, the data of HP-GL/2 or PCL XL will not be printed even though it is set to ENABLE. The data is processed as invalid. Setting ENABLE to IBM PPR III XL or EPSON FX in Japanese brands will not assure the normal operation. Setting ENABLE to ESPC/ P in overseas brands will not assure the normal operation.
	IBM PPR III XL	ENABLE DISABLE	*E *J	
	EPSON FX	ENABLE DISABLE	*E *J	
	PS3 EMULATION (C5300)	ENABLE DISABLE	*	
	ESC/ P	ENABLE DISABLE	*J *E	
	HP-GL/2	ENABLE DISABLE	*JE	
	PCL XL	ENABLE DISABLE	*JE	
ESC/ P EMULATION (Not available for overseas model) (C5300)	nSelectin	DISABLE ENABLE	*	Specifies the function of SELECT IN signal for DC1, DC3 command. When "ENABLE" is selected, if SELECT IN signal is high level in power on sequence, DC1, DC3 command is effective. When "DISABLE" is selected, DC1, DC3 command is ignored all the time (SELECT IN signal is LOW level only). Even if "EMULATION" setting of "SYS CONFIG MENU" is "AUTO", this item is effective in ESC/ P Emulation.
	NAutoFd	DISABLE ENABLE	*	Specifies the function of AUTO FEED XT signal. When "ENABLE" is selected, if AUTO FEED XT signal is low level in power on sequence, Line feed for CR code is performed. When "DISABLE" is selected, line feed for CR code is not performed (AUTO FEED XT signal is HIGH level only). Even if "EMULATION" setting of "SYS CONFIG MENU" is "AUTO", this item is effective in ESC/ P Emulation.
	IMAGE	REGULAR PHOTO	*	Specifies the conversional method of transformation from 180dpi to 300dpi.
NETWORK				This menu is for feature expansion and No Item or Value is displayed.
ENGINE DIAG MODE				Enters engine self-diagnostic mode.

The switch operation and LCD display during an engine self-diagnostic mode, which are specified by engine firmware, differ from controller firmware operating specifications. The engine self-diagnostic mode is enabled in a controller board removed configuration.

\* Operation in such a configuration is not assured.

Refer to the engine block specification for C5100 for further details if necessary.

### 3.0.2 Maintenance Utility

Maintenance utility software is used to make adjustments shown in table 3-4. Refer to the following for details on the maintenance utility software.

- 1) Maintenance utility system specification: 42514501FS01
- 2) Maintenance utility operating guide: 42514501FS02
- 3) Maintenance utility software programs:

\* The programs can be downloaded from ftp//.

Applicable Operating System	File Name
Win9xMe (Japanese version)	MuWin_JPN_Win9x.zip
WinNT/2000/XP (Japanese version)	MuWin_JPN_WinNT.zip
Win9xMe (English version)	MuWin_ENU_Win9x.zip
WinNT/2000/XP (English version)	MuWin_ENU_WinNT.zip

Table 3-0-2 Maintenance Utility Adjustment Items

	Item	Maintenance Utility	Adjustment	Operation on Operator Panel
1	PU (RSN) Board Replacement	PU board replacement function	Reprogramming of PU board EEPROM settings	Unavailable
2	CU (ARC/OWL/SPA) Board Replacement	CU board replacement function	Reprogramming of CU board EEPROM settings	Unavailable
3	Consumable Counter Display	Counter value and remaining toner amount check function	Display of printer counter values and remaining toner amounts <ul style="list-style-type: none"> <li>• Drum counters (Y, M, C and K)</li> <li>• Fuser counter</li> <li>• Belt counter</li> <li>• Toner counters (Y, M, C and K)</li> <li>• Remaining toner amounts (Y, M, C and K)</li> <li>• Half toner remaining (Y, M, C and K)</li> </ul>	Section 3.1.2.6
4	Test Printing	Test print function	Execution of printer's local print function	Section 3.1.2.5
5	Print Density Adjustment (Calibration Chip)		Print density calibration chip density input	Section 3.4
6	USB Software Update	USB software update function	USB software update	Unavailable
7	NIC Software Update	NIC software update function	NIC software update	Unavailable
8	NIC Web Page Update	NIC Web page update function	NIC Web page update	Unavailable
9	Mac Address Setting	Mac address setting function	Change of Mac addresses	Unavailable
10	Menu Setting Checking	Check function of each menu setting	Checking of menu settings that have been set inside printer	On menu map
11	Destination and PnP Information Checking	Destination and PnP information check function	Checking of printer destination, device ID and USB ID.	On menu map
12	Printer Information Checking	Printer information check function	Checking of printer Mac addresses and firmware versions	On menu map
13	Contained CPU and Memory Checking	Contained CPU and memory check function	Checking of information on CPU and on memory contained in printer	On menu map
14	Specified File Printing	Specified file print function	PRN file printing	Unavailable

### 3.1 Maintenance Modes and Their Functions

#### 3.1.1 Maintenance Menu

Maintenance menu is contained in a standard menu category. Items that can be set from Maintenance menu are as follows:

##### Maintenance Menu

Values in shaded areas are initial settings.

Category	Operator Panel Display		Function
	Item (Upper Display)	Value (Lower Display)	
Maintenance Menu	RESET MENU	ENTER	Initializes menu settings.
	SAVE MENU SETTING(S)	ENTER	Stores current menu settings.
	RESTORE STORED MENU SETTING(S)	ENTER	Changes menu settings to stored ones. Displayed only when menu settings have been stored.
	POWER SAVING	ENABLE DISABLE	Sets Power Save mode enabled/disabled. Shift time to enable Power Save mode can be changed using "POWER SAVE SHIFT TIME" on "SYSTEM CONFIG. MENU".
	NORMAL PAPER BLACK SETTING	0 +1 +2 -2 -1	Corrects print nonuniformity due to temperature variation. With faded images, change the value. With scattering or snowing images in print output of high print density, decrement the value. With faded images in print output of high print density, increment the value.
	NORMAL PAPER CLOLR SETTING	0 +1 +2 -2 -1	Corrects print nonuniformity due to temperature variation. With faded images, change the value. With scattering or snowing images in print output of high print density, decrement the value. With faded images in print output of high print density, increment the value.
	TRANSPAR-ENCY BLACK SETTING	0 +1 +2 -2 -1	Corrects print nonuniformity due to temperature variation. With faded images on transparency sheets, change the value. With scattering or snowing images in print output of high print density, decrement the value. With faded images in print output of high print density, increment the value.
	TRANSPAR-ENCY COLOR SETTING	0 +1 +2 -2 -1	Corrects print nonuniformity due to temperature variation. With faded images on transparencies, change the value. With scattering or snowing images in print output of high print density, decrement the value. With faded images in print output of high print density, increment the value.

### 3.1.2 Engine Maintenance Mode

Engine Maintenance mode includes three modes, levels 1 to 3. The level 1 is intended for assistance in checking media transport systems and the basic operations of printing systems etc. The level 2, which sets consumable counters and tests color registration adjustment function, does not require relatively special knowledge. Working, including process parameter setting, with the level 3, which contains PU individual experimental elements, takes expertise. Basically items other than those in the level 1 must not be used.

#### 3.1.2.1 Operator panel

Operating descriptions on self-diagnosis are premised on the following operator panel layout.

For ODA



For OEL/AOS



#### 3.1.2.2 Normal self-diagnostic mode (level 1)

The following is the menu of a normal self-diagnostic mode.

- Switch Scan Test
- Motor and Clutch Test
- Test Pattern Execution
- Consumable Counter Display
- Consumable Counter Display - Continuous
- Color Registration Adjustment Test
- Print Density Adjustment Test

### 3.1.2.2.1 Entering self-diagnostic mode (level 1)

1. While holding the MENU+ and MENU- keys down at the same time, turn printer power on to enter System Maintenance mode.
2. Use MENU+ or MENU- key keystrokes until "ENGINE DIAG MODE" appears (a few keystrokes), and then press the ENTER key to display "DIAGNOSTIC MODE".

DIAGNOSTIC MODE	
XX.XX.XX	FACTORY/SHIPPING

3. XX.XX.XX in the display indicates a ROM version. A factory working mode setting, which is usually set to S-MODE or SHIPPING, is at the right of the lower display.
4. Go to each self-diagnosis step by using the MENU+ or MENU- key (pressing the MENU+ or MENU- key rotates menu items).

### 3.1.2.2.2 Exiting self-diagnostic mode

1. Turn printer power off and, after ten seconds, on again.

### 3.1.2.3 Switch scan test

This self-diagnosis is used when input sensor and switch checking is made.

1. Enter the normal diagnostic mode, and press the MENU+ or MENU- key until "SWITCH SCAN" is shown on the upper display (the MENU+ key increments a test item and the MENU- key decrements a test item).

SWITCH SCAN

2. Table 3-1 lists SWITCH SCAN numbers. Press and the MENU+ or MENU- key until the SWITCH SCAN number for unit(s) to be tested shows up on the upper display (the MENU+ key increments an item and the MENU- key decrements an item).
3. In response to the press of the ENTER key, the test on the unit(s), the SWITCH SCAN number begins blinking and, carrying the current status of the unit(s) being tested, the number(s) (1 to 4) corresponding to the unit(s) are displayed.

SWITCH SCAN 00
1=H 2=L 3=H 4=L

Operate the unit(s) (figure 3-1). Indications for each unit are provided in their portion of the LCD display (Indicated meanings vary with units (sensors etc). See table 3-1 for details).

4. When the CANCEL key is pressed, the SWITCH SCAN number goes back to an indication view (stops blinking).
5. Repeat steps 2 through 4 as necessary.
6. To end the test, press the BACK key (the display is restored to the view of step 1).




Figure 3-1 Switch Sensor Positions

Table 3-1 SWITCH SCAN Display Detail

ROW SCAN NO.	1	Display	2	Display	3	Display	4	Display
SWITCHSCAN00	Tray-1 paper-end sensor	L: Paper present H: Paper absent			Entrance sensor 1	L: Paper present H: Paper absent	Entrance sensor 2	L: Paper present H: Paper absent
SWITCHSCAN01	Write sensor	L: Paper present H: Paper absent	Exit sensor	L: Paper present H: Paper absent				
SWITCHSCAN02	Toner sensor K	L: Light reflected H: Light shielded	Toner sensor C	L: Light reflected H: Light shielded	Toner sensor M	L: Light reflected H: Light shielded	Toner sensor Y	L: Light reflected H: Light shielded
SWITCHSCAN03	Cover open	L: Cover open H: Cover close						
SWITCHSCAN04								
SWITCHSCAN05								
SWITCHSCAN06								
SWITCHSCAN07								
SWITCHSCAN08	Color alignment sensor (L)	AD Value ***H	Color alignment sensor (R)	AD Value ***H	Density sensor	AD Value ***H		
SWITCHSCAN09	Fuser thermistor	AD Value ***H						
SWITCHSCAN10	Humidity sensor	AD Value ***H	Temperature sensor	AD Value ***H	Belt thermistor	AD Value ***H		
SWITCHSCAN11(Optional)	Duplex-in sensor	L: Paper absent H: Paper present	Duplex rear sensor	L: Paper absent H: Paper present	Duplex cover open sensor	L: Cover open H: Cover close	Duplex front sensor	L: Paper absent H: Paper present
SWITCHSCAN12(Optional)	Duplex bottom sensor	L: Absence detected H: Presence detected						
SWITCHSCAN13(Optional)	Tray-2 paper-end sensor	L: Paper absent H: Paper present			1st-tray sensor	L: Paper absent H: Paper present		
SWITCHSCAN14(Optional)					Tray-2 entrance sensor	L: Paper absent H: Paper present		
SWITCHSCAN15(Optional)								
SWITCHSCAN16(Optional)								
SWITCHSCAN17(Optional)								
SWITCHSCAN18(Optional)								
SWITCHSCAN19(Optional)								
SWITCHSCAN20(Optional)								
SWITCHSCAN21(Optional)								
SWITCHSCAN22(Optional)								
SWITCHSCAN23(Optional)								
SWITCHSCAN24								
SWITCHSCAN25	Image drum up/down sensor							

### 3.1.2.4 Motor and clutch test

This self-check routine is used for motor and clutch testing.

1. Go into the self-diagnostic (level 1) mode, press the MENU+ or MENU- key until upper display of "MOTOR & CLUTCH TEST" is brought up, and press the ENTER key (the MENU+ key increments a test item and the MENU- key decrements a test item).
2. The names of units to be tested are listed in table 3-2. Use the MENU+ or MENU- key until the name of a unit that is to be tested appears on the lower display (the MENU+ key increments an item and the MENU- key decrements an item).

MOTOR & CLUTCH TEST
K - ID - ID MOTOR

3. Pressing the ENTER key starts the test of the unit, blinking the displayed name of the unit. The unit is driven for 10 seconds (refer to figure 3-3).

**Note!** The view of step 2 is restored after the 10-second driving, and the unit is driven again with the press of the corresponding switch.

- Clutch solenoid on-off operations are repeated in normal printing driving (solenoids whose mechanical structures do not permit their single driving operate motors concurrently with them).

4. Use the CANCEL key to stop the drive of the unit (the display for the unit remains the same).
5. Repeat the cycle of steps 2 through 4 as needed.
6. Pressing the BACK key ends the test (the display is restored to step 1).




Figure 3-3

Table 3-2

Unit Name	Description of Control for Unit Driving	Control for Unit Driving
ID Motor (K)	Remove all the image drums (black, yellow, magenta and cyan) to drive.	Removal of IDs
ID Motor (Y)	Remove all the image drums (black, yellow, magenta and cyan) to drive.	Removal of IDs
ID Motor (M)	Remove all the image drums (black, yellow, magenta and cyan) to drive.	Removal of IDs
ID Motor (C)	Remove all the image drums (black, yellow, magenta and cyan) to drive.	Removal of IDs
Belt Motor	Remove all the image drums (black, yellow, magenta and cyan) to drive.	Removal of IDs
Fuser Motor	-	-
Cassette 1 Hopping Motor	Remove the cassette 1 to drive.	Removal of Cassette 1
Hopping Solenoid	-	-
Duplex Motor	-	-
Duplex Clutch	-	-
Duplex Solenoid	-	-
Cassette 2 Motor	Remove the cassette 2 to drive.	Removal of Cassette 2
Cassette 2 Clutch	-	-
ID Up/Down	-	-
Fan1 Test (Power Supply Fan)	-	-
Fan2 Test (Fuser Fan)	-	-

3.1.2.5 Test printing

This self-diagnostic routine is used when PU-inside test patterns are printed. The other test patterns are in controller's storage.

1. Go into the self-diagnostic (level 1) mode, press the MENU+ or MENU- key until "TEST PRINT" comes into view in the upper display, and press the ENTER key (the MENU+ key is for test item increment, and the MENU- key for test item decrement).
2. Items applied only to test printing are shown on the lower display. Press the MENU+ or MENU- key until an item to be set appears, and hit the ENTER key (the MENU+ key is for item increment, and the MENU- key for item decrement) [When items need not be set (must be left at their defaults), go to step 5].
3. Press the MENU+ or MENU- key and, when the item that has been set in step 2 is reached, press the Enter key. The item and its setting are displayed on the upper and lower panel, respectively. The setting is incremented by pressing the MENU+ key, and decremented by pressing the MENU- key (the last displayed setting is applied). Pressing the BACK key determines the setting, restoring the view of step 2. Repeat step 3 as necessary.

TEST PATTERN
1

Display	Set Value	Function
PRINT EXECUTE	—	Starts printing at the press of the ENTER key, and ends the printing at the press of the CANCEL key. (Page basis)
TEST PATTERN	0	0: Prints a blank page. 1 to 7: (Print a pattern). 8 to 15: Print a blank page.
CASSET	TRAY1	Selects a unit in which paper is to be loaded.
	TRAY2	When the printer is not equipped with the tray 2, TRAY2 is not displayed.
	FF	
PAGE	0000	Sets the number of test pages printed.
COLOR	ON	Selects color or monochrome printing.
	OFF	
DUPLEX	2 PAGES STACK	Performs two-page stack duplex printing.
	OFF	Establishes duplex-off printing.
	1PAGES STACK	Performs one-page stack duplex printing.

- Values in shaded areas are initial settings. Values established are applicable only to this test mode (they are not written into EEPROM).

**Notes!**

PAGE Setting ..... Should the ONLINE key be pressed after a digit is shifted by a touch of the MENU+ or MENU- key, the setting is incremented. In the event of the press of the CANCEL key after such a digit shift, the setting is decremented.

COLOR Setting ..... While the COLOR setting is set to ON, pressing the ENTER key displays the following on the panel.

Print Setting for Colors... The press of the MENU+ or MENU- key shifts a value. The ONLINE or CANCEL key is used for switching between ON and OFF. The BACK key restores original display.


COLOR	→	Y : ON M : ON
ON		C : ON K : ON

4. With "PRINT EXECUTE" on the lower display after step 2, when the ENTER key is pressed, test printing is executed using the values set in steps 2 and 3. Pressing the CANCEL key stops the test printing.


Any of the alarms shown in the table of operator panel display description (see below), which has been detected during the initiation or progression of test printing, appears on the panel display, suspending the printing (for the description of errors, see section 3.1.2.9 Operator Panel Display, which messages differ from those displayed in PU test printing).

### Print Patterns


Patterns 0 and 8 to 15 ... print a blank page.




Pattern 1




Pattern 2




Pattern 3




Pattern 4



Pattern 5



Pattern 6



Pattern 7

- The following messages are showing during printing.

P=***
W=***

P: Number of test pages printed (prints)

W: Wait time for printing (in seconds)

- Use the MENU+ key to change the display.

T=*** U=***[***]
H=***% B=***[***]

T: Environment temperature measurement (in Celsius)

U: Heater temperature measurement (in Celsius)

H: Environment humidity measurement (in percent)

B: Belt humidity measurement (in Celsius)

- With the press of the MENU+ key, the display is changed.

KTR=*.*** YTR=*.***
MTR=*.*** CTR=*.***

YTR, MTR, CTR and KTR are colors' respective transfer voltage settings (in KV).

- Pressing the MENU+ key changes the display.

KR=**** YR=****
MR=**** CR=****

YR, MR, CR and KR are colors' respective image drum resistance values (in megohms).

- The display is switched by pressing the MENU+ key.

ETMP=*** UTMP=***
REG=**** EXIT=****

ETMP: Environment temperature measurement (in Celsius)

UTMP: Heater temperature measurement (in Celsius)

REG: Hopping motor speed setting

EXIT: Fuser motor speed setting

- The MENU+ key switches the display.

KID=*** YID=***
MID=*** CID=***

KID, YID, MID and CID are image drum motor speed settings.

- Pressing the MENU+ key changes the display.

BELT=****

BELT: Belt motor speed setting

- With the press of the MENU+ key, the display is switched.

HT:**** CH:****
DB:****

HT, CH and DB are high-voltage table IDs.

- Pressing the MENU+ key changes the display.

TR1:*****
TR2:*****

TR1 and TR2 are high-voltage table IDs.

5. Repeat steps 2 through 4 if necessary.
6. Press the CANCEL key to end the test (the display is restored to step 1).

## 3.1.2.6 Consumable counter display

The self-diagnosis is used to indicate consumable consumption status.

1. After entering the normal self-diagnostic mode, press the MENU+ or MENU- key until "CONSUMABLE STATUS" appears on the upper display, and hit the ENTER key (the MENU+ key is for test item increment, and the MENU- key for test item decrement).
2. By pressing the MENU+ or MENU- key, the consumption status of consumables comes into view item by item (the ONLINE and CANCEL keys are invalid).
3. Pressing the BACK key ends the test (the display of step 1 is restored).

Item	Top Display	Bottom Display	Format	Unit	Details
Fuser unit	FUSER UNIT	***** PRINTS	Decimal	Print	Shows the number of pages printed (prints) after installation of a new fuser unit to date.
Belt unit	TR BELT UNIT	***** IMAGES	Decimal	Image	Converts into a count on an A4-size-page basis at 3 pages per job, and shows, the number of pages impressed (images) after installation of a new belt unit to date.
ID unit - black	BLACK ID UNIT	***** IMAGES	Decimal	Print	Convert the numbers of revolutions of image drum units after the installation of those units to date into counts on a letter- (A4-) size-page basis at 3 pages per job and show it.
ID unit - yellow	YELLOW ID UNIT	***** IMAGES	Decimal	Print	
ID unit - magenta	MAGENTA ID UNIT	***** IMAGES	Decimal	Print	
ID unit - cyan	CYAN ID UNIT	***** IMAGES	Decimal	Print	
Toner - black	BLACK TONER	***%	Decimal	%	Show the amounts of toner used.
Toner - yellow	YELLOW TONER	***%	Decimal	%	
Toner - magenta	MAGENTA TONER	***%	Decimal	%	
Toner - cyan	CYAN TONER	***%	Decimal	%	

## 3.1.2.7 Consumable counter display - continuous

The self-diagnosis is used to indicate the consumable life-cycle consumption status of a printer. The status means those count values for consumables which are not initialized even after replacement of the consumables, and is counted without break.

1. Enter the normal self-diagnostic mode, press MENU+ or MENU- key until the upper display "PRINTER STATUS" appears, and press the Enter key (the MENU+ key is for item increment, and the MENU- key for item decrement).
2. When the MENU+ or MENU- key is pressed, the life-cycle consumption status of the consumables shows up item by item (the ONLINE and CANCEL keys are invalid).
3. Pressing the BACK key ends the test (flips the display back to step 1).

Item	Top Display	Bottom Display	Format	Unit	Details
Total sheets fed	TOTAL SHEETS FEED	***** PRINTS	Decimal	Print	Shows the total number of sheets fed, including blank pages.
Print - black	BLACK IMPRESSIONS	***** IMAGES	Decimal	Print	Show the numbers of pages (images) impressed using image drums.
Print - yellow	YELLOW IMPRESSIONS	***** IMAGES	Decimal	Print	
Print - magenta	MAGENTA IMPRESSIONS	***** IMAGES	Decimal	Print	
Print - cyan	CYAN IMPRESSIONS	***** IMAGES	Decimal	Print	

## 3.1.2.8 Operator panel display

## Display

LCD (English) (□ means no display in upper line)	Ready LED	Attention LED	Description	Level
ONLINE .xxxx tttttt	ON	Varies	Shows on-line status.	Normal
OFFLINE .xxxx tttttt	OFF	Varies	Shows off-line status.	Normal
FILE ACCESSING	Varies	Varies	Device accessing during the operation of accounting system operating.	Normal
DATA ARRIVE .xxxx tttttt	Varies	Varies	Data receiving, process not started yet. Displayed mainly during P/JL process without text print data or during job spooling.	Normal
PROCESSING .xxxx	Blink	Varies	Data receiving or output processing.	Normal
DATA .xxxx	Varies	Varies	Un-printed data remains in Buffer. Waiting for data to follow.	Normal
PRINTING tttttt	Varies	Varies	A printer is printing.	Normal
PRINT DEMO PAGE	Varies	Varies	Performing Demo Print. Not displayed when printing user defined demo-pages (Shows "PRINTING" in this case)	Normal
PRINT FONT	Varies	Varies	Printing Fonts. Same as in all fonts (PCL,PSE,IBMPPR,EPSON FX)	Normal
PRINT MENU MAP	Varies	Varies	Printing Menu Map.	Normal
PRINT FILE LIST	Varies	Varies	Printing File List.	Normal
PRINT ERROR LOG	Varies	Varies	Printing Error Logs.	Normal
□ COLLATE COPY iii/jjj	Varies	Varies	Collate printing. iii: The number of copy in printing. jjj: The total number of printing. When the total number of printing is 1, it is a normal printing display.	Normal
□ COPY kkkk/llll	Varies	Varies	Copy printing. kkk: The number of pages in printing. lll: The total number of printing. When the total number of copy is 1, it is a normal printing display.	Normal
CANCELING JOB	Blink	Varies	Indicates that job cancellation has been instructed and data is being ignored until the job completion. (Display for a certain period (seconds) is requested. If it immediately disappears, cannot tell whether or not it was cancelled.)	Normal
CANCELING JOB (USER DENIED)			Job cancelled because of no permission for printing (Related to JobAccount) 1. Job received from a user not permitted to print. 2. Color Job received from a user not permitted to print in color.	

LCD (English) (□ means no display in upper line)	Ready LED	Attention LED	Description	Level
CANCELING JOB (BUFFER FULL)	Blink	Varies	Job cancelled because the log saving area in printer is running out and "Job cancelled when log full occurs" is set. (Related to JobAccount)	Normal
CANCELING JOB (JAM)			Job cancelled and the data is being discarded till the end of the Job because JAM occurs when "JAM RECOVERY" is set to OFF.	
□ WARMING UP	Varies	Varies	Warming up.	Normal
□ OPTIMIZING TEMP	Varies	Varies	Because the drum temperature is high, printing is temporarily suspended. Or, the printer is waiting for implementation of heat measure for media switch from narrow paper to wide paper.	Normal
□ POWER SAVE	Varies	Varies	A printer is in power save mode. Displayed in a combination of other message in the first line.	Normal
□ ADJUSTING COLOR	Varies	Varies	Auto registration adjusting in progress	Normal
□ ADJUSTING DENSITY	Varies	Varies	Auto tone adjusting in progress	Normal
□ ADJUSTING DENSITY	Varies	Varies	Auto density adjusting in progress	Normal
			Downloading PU firmware (Displayed messages are output by the PU firmware.)	Normal
□ ORDER * TONER	Varies	ON	Toner low. Displayed in a combination of other message in the first line. If "LOW TONER=STOP" is set in menu, ATTENTION LED blinks and the printer shifts to Off-line. When a user presses On-line switch, ATTENTION LED (stops blinking and) lights on and printing can continue until TONER EMPTY. Y M C K This message is also displayed when * waste toner box is near full.	Warning
□ * WASTE TONER FULL.REPLACE TONER	Varies	ON	The printer can still print. Allows printing about 50 pages of A4 size at 5% density, then stops with Waste Toner Full Error(414,415,416) again. The LCD message indicates that the Waste Toner box is full. Y M C	Warning
PRESS ONLINE SW INVALID DATA	Varies	Varies	Invalid data was received. Press the On-line switch and eliminate the warning. Displayed when unsupported PDL command is received or a spool command is received without HDD.	Warning

LCD (English) (□ means no display in upper line)	Ready LED	Attention LED	Description	Level
□ PS3 EMUL ERROR	Blink	Varies	Interpreter has detected an error due to the following reason. Receive data after this is ignored until the job completion. When the job is completely received, this is automatically cleared. - The job has a grammatical error. - The page is complicated, and VM was used up.	Warning
□ ORDER * IMAGE DRUM	Varies	ON	Drum near life. (warning) Displayed in a combination of other message in the first line. Y M C K	Warning
□ ORDER FUSER	Varies	ON	Fuser unit near life. (Warning)	Warning
□ ORDER BELT	Varies	ON	Belt unit near life. (warning)	Warning
□ FUSER LIFE	Varies	ON	If a fuser life error occurs and a user opens/closes the cover or reboots the printer, this phenomenon happens. When the printer printed 500 pages, the error occurs again.	Warning
□ BELT LIFE	Varies	ON	If a belt life error occurs and a user opens/closes the cover or reboots the printer, this phenomenon happens. When the printer printed 500 pages, the error occurs again.	Warning
□ * TONER EMPTY	Varies	ON	If a toner empty occurs and a user opens/closes the cover or reboots the printer, this phenomenon happens. When the printer printed approx. 50 pages (A4, density 5%), the error occurs again. Y M C K	Warning
□ * DRUM LIFE	Varies	ON	If a drum life error occurs and a user opens/closes the cover or reboots the printer, this phenomenon happens. When the printer printed 500 pages, the error occurs again. Y M C K	Warning
□ BELT REFLEX ERROR	Varies	ON	Belt Reflex Check error. This is not a user-level error. (If it happens, change the mode to Shipping mode. See the Maintenance Manual.)	Warning
□ DENSITY SHUTTER ERROR2			This is not a user-level error. (If it happens, change the mode to Shipping mode. See the Maintenance Manual.)	Warning
□ DENSITY SHUTTER ERROR1			This is not a user-level error. (If it happens, change the mode to Shipping mode. See the Maintenance Manual.)	Warning

LCD (English) (☐ means no display in upper line)	Ready LED	Attention LED	Description	Level
☐ DENSITY COLOR CALIBRATION ERROR			This is not a user-level error. (If it happens, change the mode to Shipping mode. See the Maintenance Manual.)	Warning
☐ DENSITY COLOR SENSOR ERROR			This is not a user-level error. (If it happens, change the mode to Shipping mode. See the Maintenance Manual.)	Warning
☐ DENSITY BLACK CALIBRATION ERROR			This is not a user-level error. (If it happens, change the mode to Shipping mode. See the Maintenance Manual.)	Warning
☐ DENSITY BLACK SENSOR ERROR			This is not a user-level error. (If it happens, change the mode to Shipping mode. See the Maintenance Manual.)	Warning
☐ * IMAGE DRUM SMEAR ERROR			This is not a user-level error. (If it happens, change the mode to Shipping mode. See the Maintenance Manual.) Y,M,C,K	Warning
☐ * LOW DENSITY ERROR			This is not a user-level error. (If it happens, change the mode to Shipping mode. See the Maintenance Manual.) Y,M,C,K	Warning
☐ REGISTRATION ERROR 1	Varies	ON	Registration error This is not a user-level error. (If it happens, change the mode to Shipping mode. See the Maintenance Manual.)	Warning
☐ SENSOR CALIBRATION ERROR	Varies	ON	Sensor calibration error This is not a user-level error. (If it happens, change the mode to Shipping mode. See the Maintenance Manual.)	Warning
☐ REGISTRATION ERROR 2	Varies	ON	Gamma error This is not a user-level error. (If it happens, change the mode to Shipping mode. See the Maintenance Manual.)	Warning
☐ REGISTRATION ERROR 3	Varies	ON	Gamma error This is not a user-level error. (If it happens, change the mode to Shipping mode. See the Maintenance Manual.)	Warning
☐ REGISTRATION ERROR 4	Varies	ON	Gamma error This is not a user-level error. (If it happens, change the mode to Shipping mode. See the Maintenance Manual.)	Warning
☐ REGISTRATION ERROR 5	Varies	ON	Gamma error This is not a user-level error. (If it happens, change the mode to Shipping mode. See the Maintenance Manual.)	Warning
☐ REGISTRATION SENSOR ERROR 2	Varies	ON	Registration sensor error This is not a user-level error. (If it happens, change the mode to Shipping mode. See the Maintenance Manual.)	Warning
☐ REGISTRATION SENSOR ERROR 3	Varies	ON	Registration sensor error This is not a user-level error. (If it happens, change the mode to Shipping mode. See the Maintenance Manual.)	Warning
☐ REGISTRATION SENSOR ERROR 4	Varies	ON	Registration sensor error This is not a user-level error. (If it happens, change the mode to Shipping mode. See the Maintenance Manual.)	Warning

LCD (English) (□ means no display in upper line)	Ready LED	Attention LED	Description	Level
□ REGISTRATION SENSOR ERROR 5	Varies	ON	Registration sensor error This is not a user-level error. (If it happens, change the mode to Shipping mode. See the Maintenance Manual.)	Warning
□ ttttt EMPTY	Varies	Varies	“ttttt” tray is empty. Treated as Warning until printing to the empty tray is designated. MPTRAY EMPTY is displayed when paper feed from MPTRAY is attempted, but the tray is empty. When printing of the job is completed, this warning disappears if a user opens/closes the cover or reboots the printer.	Warning
□ HARD DISK FULL	Varies	ON	Disk-full has occurred. Because this is a temporary warning, it remains until the end of the job and disappears.	Warning
□ DISK WRITE DISABLED	Varies	ON	An attempt to write in a read-only file was done. Because this is a temporary warning, it remains until the end of the job and disappears.	Warning
□ COLLATE FAIL	Varies	OFF	The data of MOPY is memory-full.	Warning
□ INVALID ID. JOB REJECTED	Varies	ON	Job cancelled because of no permission for printing (Related to JobAccount) Cleared by pressing ON-LINE switch. 1. Job received form a user not permitted to print 2. Color Job received form a user not permitted to print in color.	Warning
□ LOG BUFFER FULL. JOB REJECTED			Job cancelled because the log saving area in printer is running out and “Job cancelled when log full occurs” is set. (Related to JobAccount)Cleared by pressing ON-LINE switch.	
□ DISK USE FAILED	Varies	ON	A disk error other than No.29/30 has occurred. Operation that does not involve a disk is available.	Warning
□	Varies	Varies	An error occurred when renewing PU firmware. This is not a user-level error. (Displayed messages are output by the PU firmware.)	Warning
LOAD mmm IN MP TRAY AND PRESS ONLINE SWITCH	ON	OFF	Manual paper feed is required. Manually insert the paper shown by mmm.	Warning

### 3.1.2.9 Color registration adjustment test

This self-diagnosis (color registration adjustment test) is used to adjust and diagnose printer's color registration. Appropriate troubleshooting steps are to be used for recovery from errors occurred in the color registration adjustment test.

1. Enter the self-diagnostic mode (level 1), press and hold the MENU+ and MENU- keys until "REG ADJUST TEST" appears on the upper display, and then press the ENTER key (the MENU+ key increments an item and the MENU- key decrements an item).
2. Press and hold the MENU+ and MENU- keys until a color registration adjustment test item to be tested is displayed.
3. With the press of the ENTER key, the test that is showing is executed. \* Pressing the CANCEL key during the test suspends the test.
4. Upon completion of the test, the result of the test (OK or a NG error name) is provided on the upper display, and "\*\*\*\*\*RESULT" on the lower display, the operation of the step 2 being enabled.
5. Repeat the steps 2 to 3 when necessary.
6. Press the BACK key to end the test.

#### Color Registration Adjustment Items

SUB MENU	Description
REG ADJ EXECUTE	Performs color registration adjustment.
REG ADJ RESULT	Used to see the result of color registration adjustment.
BLT REFLECT TEST	Performs the OK or NG judgment of color registration adjustment belt reflectivity.
BLT REFLECT RSLT	Used to see the result of OK or NG judgment of color registration adjustment belt reflectivity.

### 3.1.2.10 Print density adjustment test

This self-diagnosis is used to perform the test with respect to printer's print density adjustment function and to see the result of the test. The test determines whether printer's print density adjustment system is proper.

1. Enter the self-diagnostic mode (level 1), press and hold the MENU+ and MENU- keys until "DENSITY ADJUST TEST" appears on the upper display, and then press the ENTER key (the MENU+ key increments an item and the MENU- key decrements an item).
2. Press and hold the MENU+ and MENU- keys until a print density adjustment test item to be tested is displayed.
3. With the press of the ENTER key, the test that is showing is executed. \* Pressing the CANCEL key during the test suspends the test.
4. Upon completion of the test, the result of the test (OK or a NG error name) is provided on the upper display, and "\*\*\*\*\*RESULT" on the lower display, the operation of the step 2 being enabled.
5. Repeat the steps 2 to 3 when necessary.
6. Press the BACK key to end the test.

#### Print Density Adjustment Test Items

SUB MENU	Description
DENS ADJ EXECUTE	Performs print density adjustment.
DENS ADJ RESULT	Used to see the result of print density adjustment.
DENS SENSOR TEST	Performs the OK or NG judgment of the print density adjustment sensor.

### 3.1.3 Printing on Controller-Equipped Printer on a Standalone Basis

#### Menu Map Printing

Information, including program versions, controller block configuration and network configuration, is printed.

Operation:

1. Press the MENU+ key several times to display "INFORMATION MENU";
2. Press the ENTER key to display "PRINT MENU/EXECUTE"; and
3. Press the ENTER key, or

Alternatively press the push switch located above the network connector on the back of the printer main body for two seconds or more.

#### Demo Printing

Demonstration patterns for destinations stored in ROM are printed.

Operation:

1. Press the MENU+ key several times to display "INFORMATION MENU".
2. Press the ENTER key.
3. Press the MENU+ key several times to display "DEMO1/EXECUTE".
4. Press the ENTER key.

### 3.1.4 Switch Press Functions at Printer Power-On

Switch functions at printer power-on are as follows. The following switches are enabled, when pressed and held until "RAM CHECK" appears on the upper LCD display and, on the lower LCD display, three or four asterisks (\*) appear.

#### 1. BACK key, MENU- key and CANCEL key

Enabled only for CU-F/W G1.26/X1.26 and earlier versions. After switch press is recognized, CU firmware activation is performed to restore CU board EEPROM to its factory shipped configuration.

#### 2. BACK key, MENU+ key and CANCEL key

Enabled only for CU-F/W G1.26/X1.26 and earlier versions. Performs forced HDD initialization. It should be noted that data, such as not-yet-printed data and JobAccount log data, is erased with the initialization (see 5.5.4 "Actions Taken after Forced HDD/Flash Initialization").

#### 3. MENU+ key, MENU- key and CANCEL key

Enabled only for CU-F/W G1.26/X1.26 and earlier versions. Performs forced resident Flash initialization. The initialization causes network inoperability because the initialization erases data, such as NIC firmware and Mac addresses (see 5.5.4 "Actions Taken after Forced HDD/Flash Initialization").

For CU-FW \*1.27 and later versions, the functions of the above (1) to (3) are replaced with those of the system maintenance menu, MAINTENANCE MENU.

#### 4. MENU+ key, MENU- key and ENTER key

Performs printer activation in CU program update mode. Printer activation in that mode causes network inoperability because the activation disables DLM function.

#### 5. BACK key, ONLINE key and CANCEL key

Performs CU program activation without activating object(s) which have been added in download mode etc.

#### 6. MENU+ key and MENU- key

Performs system maintenance menu activation.

#### 7. BACK key, MENU- key and ENTER key

Performs printer activation in a mode which ignores warnings/errors and which at all times keeps printer on-line state (a factory support function).

#### 8. ONLINE key

Performs printer activation in an exclusive mode which downloads objects, such as networks and USBs.

#### 9. ENTER key

Performs Admin menu activation.

### 3.2 Adjustments after Parts Replacement

Adjustments required after parts replacement are described below. The adjustment and correction of color registration must be performed without exception.

Replaced Part	Adjustment
LED Head	Not required.
Image Drum Cartridge (Any of Y, M, C and K)	Not required.
Fuser Unit	Not required.
Belt Unit	Not required.
PU (RSN Board)	Copying of EEPROM data *Note
CU (ARC Board / OWL Board / SPA Board)	Copying of EEPROM data *Note
Shutter	Setting of correction value for density detection calibration chip

**Note:** When a PU (RSN board) is replaced with a new one, data may not be read out of its EEPROM. In such cases, color balance must be adjusted.

### 3.2.1 Precautions in replacing engine controller board

When replacing an engine controller board (RSN PWB), read EEPROM data from the board and copy it onto a new board, using maintenance utility software. When SERVICE CALL 105 (an engine EEPROM error) appears on the operator panel, engine controller board replacement to a new board should be made.

Version read function (fuse cut-off) is disabled when EEPROM data cannot be copied from a engine controller board (RSN PWB) being replaced, or after an engine controller board is replaced with a new one. In such cases, printer mode switching from Factory to Shipping must be processed by the PjL command.

#### Procedure 1 for changing printer mode from Factory to Shipping

(Operation from Control Panel)

1. Enter the self-diagnostic mode by turning the printer on while holding the MENU+ and MENU- keys down concurrently.
2. Press and hold the MENU+ and MENU- keys until "LOCAL PARAMETER SET" appears on the upper display, and then press the ENTER key.
3. Press MENU+ and MENU- keys to show "FACTORY MODE" on the upper display and, on the lower display, either "FACTORY MODE" or "SHIPPING MODE" to be desired to be set.
4. Use the combination of the CANCEL and ONLINE keys for three seconds to complete the programming.
5. Press the Back key to end the test.

Upper Display	Lower Display	Function Detail
FACTORY MODE	FACTORY MODE	Fuse cut-off disabling mode
	SHIPPING MODE	Fuse cut-out enabling mode

#### Procedure 2 for changing printer mode from Factory to Shipping

(Operation by PjL Commands)

[Description]

1. Sending appropriate PjL file to printer to establish Shipping mode.
2. Turning printer's power on or sending reboot command (PjL file), to complete setting.

[Procedure]

Perform the following steps in response to MS-DOS prompts:

1. Execute Copy /b Pjl\_ship.bin prn.
2. Execute Copy /b Pjl\_reboot.bin prn, or turn the printer off and on again.

[PjL Files Required]

1. Pjl\_ship.bin
2. Pjl\_reboot.bin

**Note!** Note that, because EEPROM (engine controller board) replacement clears information on the life of a belt unit, toner, image drum units, etc., errors are introduced in the control of the life until they are replaced after the EEPROM replacement. Counts cleared upon EEPROM replacement are as follows. The counts except Total Sheets Fed are cleared, the errors being eliminated, at the point where the units for which the counts are provided have been replaced with new ones.

Item	Description	Count Description
Fuser unit	Fuser unit life count	A value converted on a A4-size-paper basis from number of pages printed (prints) after installation of a new fuser unit
Belt unit	Belt unit life count	A value converted on a A4-size-paper basis from number of pages impressed (images) after installation of a new belt unit
Image drum unit - Black Image drum unit - Yellow Image drum unit - Magenta Image drum unit - Cyan	Respective life counts of image drum units	Values converted on a A4-size-paper basis from numbers of revolutions after installation of new image drum units
Toner - Black Toner - Yellow Toner - Magenta Toner - Cyan	Respective counts of toner amounts used	Numbers of dots printed
Total number of sheets fed	Printer life count	Total number of sheets fed
Pages - Black Pages - Yellow Pages - Magenta Pages - Cyan	Respective numbers of pages impressed (images) with image drums	Numbers of pages impressed (images) from installation of new image drum units.

### 3.2.2 EEPROM Setting after ARC Board / OWL Board / SPA Board Replacement

When ARC/OWL/SPA board replacement, data in user-used board EEPROM is to be copied onto new boards using maintenance utility software (to allow new boards to inherit user-defined information and font installation information). When user-used EEPROMs are unusable due to its problem, new boards, whose destinations and must have been set, are to be used. Also new-EEPROM destinations must have been set.

### 3.2.3 Destination Setting (Check Method: Printing demo page)

Destination setting is to be conducted at final setting after part installation in printers. The destination setting for each printer, which defaults to OEL, is to be set to the destination of the printer without exception at the time it is shipped.

**Note!** Destination settings are stored in ARC board / OWL board / SPA board EEPROM.

1. Maintenance-use boards: Destination setting for maintenance-use boards to Japan indirect sales, ODA, OEL and APS is not performed. They are shipped with the destination settings set to their default.
2. Setting from operator panel: Each printer is booted in Maintenance mode and its destination is set.
  - While holding the MENU+ and MENU- keys down, turn on the printer.
  - After "MAINTENANCE MENU" appears, the display changes to "OKIUSER."
  - Press the MENU+ key, select destination-setting "OKIUSER" and press the ENTER key.
  - "JP\*" is shown on the lower display.
  - Press the ENTER key, select a destination using the MENU+ or MENU- key, and hit the ENTER key.
  - Press the BACK key to confirm the selection.
  - With the two presses of BACK key or the one press of ONLINE key, the printer is restarted with the destination changed.

#### 3. Description

C5100/5300 printers to Japan domestic and overseas destinations share a ROM. Destination setting must be performed where the ROM is used in printers to other-than-OEL destinations (destination settings default to OEL). Destination settings are stored in ARC board EEPROM. Program ROM version changes return destination settings to their initial values. Destination setting for maintenance-use boards, which destinations are not set at the time of shipment, is to be carried out when they are used.

If destination is OEL and Russian compatible panel is installed, you need to change CODESET in CONFIG MENU in SYSTEM MAINTENANCE MENU to TYPE2 and reboot. (Refer to Section 3.0.1 System Maintenance Menu.)

## 3.3 Print Density Adjustment

Auto Density Adjustment mode is set to [AUTO] at printer shipment, which may cause print density to be out of its appropriate balance during printer operation. In such cases, the density is to be adjusted.

**Notes!** Print density adjustment is to be performed with printers at rest. Do not adjust print density during printer warming-up.

1. Press the MENU+ or MENU- key several times to show [COLOR MENU], and press the ENTER key.
2. Press the MENU+ or MENU- key to display [DENSITY ADJUSTMENT/ RESET].
3. Press the ENTER key.

Auto print density adjustment starts.

### 3.4 Print Density Adjustment (Calibration Chip)

Print Density Input to Print Density Detection Calibration Chip

1. Each PU is to be programmed with a calibration target correction value (the last two characters of barcode information, about which see the illustration shown below) that is a shutter label marking.

With shutter, sheet color, print density sensor or PU board replacement, correction value reprogramming must be performed.


Setting from operator panel:

- While holding the MENU+ and MENU- keys down, turn the printer on.
- After "MAINTENANCE MENU" appears, the display changes to "OKIUSER."
- Press the MENU+ key seven times to select "DIAGNOSTIC MODE."
- Press the MENU+ and ONLINE key. "ENGINE DIAG LEVEL2" is displayed.
- Press the MENU key two times to select "ENGINE PARAMETER SET."
- Press the ONLINE or CANCEL key to show "CHIP DISPERSION ADJUST 00H."
- Pressing the ENTER key blinks the first or second character of the display.
- Press the ONLINE or CANCEL key to set a correction setting.
- Press and hold the ONLINE or CANCEL key about two seconds to confirm the correction setting. The blinking correction setting becomes stay illuminated, bearing with an asterisk (\*).
- The printer restarts and the correction setting takes effect.

#### ① Information written

From left:

- One asterisk (\*) character
- Four-digit date (ID barcode) system
  - One-digit year (only one-digit x of 200x)
  - One-digit month (X, Y and X, for Oct., Nov. and Dec.)
  - Two-digit day
- Four digits Filled with zeros 0000
- Two-digit correction value
  - (In the same format as that for data manually input to printer)
  - 00 to 04, for 0 to 4. FF to FC, for -1 to -4.



## 4. REGULAR MAINTENANCE

### 4.1 Parts Replaced Regularly

Users are recommended to replace parts periodically according to the table below. (Print quality cannot be assured and damages may occur, when the parts are not replaced.)

Part Name	Time of Replacement	Condition for Replacement	Adjustment (after replacement)
Toner cartridge	When [REPLACE TONEER] is displayed.	5,000 pages are printed. (5% duty)	
ID	When [REPLACE IMEGE DRUM] is displayed.	15,000 pages are printed. (3P/J)	
Fuser unit	When [REPLACE FUSER] is displayed.	45,000 pages are printed.	
Belt unit	When [REPLACE BELT] is displayed.	50,000 pages are impressed. (3P/J)	

Parts are replaced periodically by users.

### 4.2 Cleaning

Clean the internal and external sections of the printer with waste and a small vacuum cleaner as required.


**Note:** Do not touch the image drum terminals, the LED lens array, and the LED head connector.

### 4.3 Cleaning the LED Lens Array

Clean the LED head array while white bands or lines (white-out, faint print) appear in the vertical direction on a printed page.

**Note:** Be sure to clean the LED lens array with the LED lens array cleaner. (the LED head cleaner is packed together with the toner cartridge.)

White band, white stripe  
(Void or light printing)



### 4.4 Cleaning the Pick-up Roller

Clean the pick-up roller if lines appear in the vertical direction on the printed page.

**Note:** Use a soft cloth in order to avoid scratching the roller surface.

## 5. TROUBLESHOOTING PROCEDURES

### 5.1 Precautions before troubleshooting

- (1) Confirm the basic inspection items described in the user manual.
- (2) Obtain as much information regarding the problem from the user as possible.
- (3) Check the printer in a condition close to that upon generating the problem.

### 5.2 Precautions before handling an abnormal image

- (1) Confirm that the environment for using this printer is appropriate.
- (2) Confirm that consumables (toner, drum cartridge) are replaced appropriately.
- (3) Confirm that paper is accurate. Refer to paper specifications.
- (4) Confirm that the drum cartridge is set appropriately.

### 5.3 Precautions upon handling an abnormal image

- (1) Do not touch or allow foreign objects to contact the OPC drum surface.
- (2) Do not expose the OPC drum to direct sunlight.
- (3) Do not touch the fuser unit as it is heated significantly.
- (4) Do not expose the image drum to light for longer than five minutes in room temperature.

## 5.4 Preparing for Troubleshooting


### (1) Operator panel display

Problems that occur with the printer are indicated in the LCD.

Apply proper remedies according to the message indicated in the LCD.

## 5.5 Troubleshooting Procedure

Confirm the problem in the following method when the printer generates a problem.



## 5.5.1 LCD message list

When the printer detects a non-recoverable error, the following service call error is displayed in the LCD.

Service call  
nnn: error

**Note:** nnn is an error code.

When [Service call] is displayed, error information that corresponds to the error code appears in the bottom line in the LCD. Be sure to make a note of, and report to related departments, the descriptive information (such as numeric values that indicate addresses), which is used for troubleshooting. Error codes, their definitions and remedies are described in Table 5-1-1.

Table 5-1-1 Operator Alarm (1/5)

Display on Operator Panel	Ready LED	Attention LED	Description	Code nnn
LOAD mmm/ppp AND PRESS ONLINE SWITCH nnn: ttttt MEDIA MISMATCH	OFF	Blink	The media type in the tray does not match the print data. Load mmm/ppp paper in ttttt tray. MPTRAY (MP Tray) TRAY1 (Tray 1) TRAY2 (Tray 2)	460 461 462
LOAD mmm/ppp AND PRESS ONLINE SWITCH nnn: ttttt SIZE MISMATCH	OFF	Blink	The media size or both media size and media type in the tray does not match the print data. Load mmmmmmm/pppppp paper in ttttt tray. MPTRAY (MP Tray) TRAY1 (Tray 1) TRAY2 (Tray 2)	460 461 462
NETWORK CONFIG WRITING	ON	ON	Saving the Network configuration to Flash memory when setting item which relate to Network was changed.	
NETWORK INITIAL WAIT A MOMENT	Varies	Varies	Network initializing.	
LOAD mm nnn: ttttt EMPTY	OFF	Blink	Printing request is issued to an empty ttttt tray. Printing request is issued to Tray2 which is opened.. Printing request is issued to Tray1 which is opened when Tray2 is not exist. Load Mmmmmmm paper. TRAY1 (Tray 1) TRAY2 (Tray 2)	491 492
LOAD mmm AND PRESS ONLINE SWITCH nnn:MP TRAY EMPTY	OFF	Blink	Paper feed from MPTRAY is attempted, but the tray is empty. Loading mmm paper and pressing the On-line switch will start printing. MP TRAY (MP Tray)	490
INSTALL PAPER CASSETTE nnn:TRAY1 OPEN	OFF	Blink	Tray1 cassette that is a paper path for the paper loaded from Tray2 to be printed to is removed.	440
INSTALL PAPER CASSETTE nnn:TRAY1 MISSING	OFF	Blink	Tray1 cassette of paper to which printing is intended is removed, and paper cannot be fed.(When Tray2 exists)	430
ADD MORE MEMORY nnn: MEMORY OVERFLOW	OFF	Blink	Memory capacity overflows. Press ON-LINE switch so that printing continues. Install expansion RAM or decrease data size.	420

Table 5-1-1 Operator Alarm (2/5)

Display on Operator Panel	Ready LED	Attention LED	Description	Code nnn
REPLACE TONER nnn:* WASTE TONER FULL	OFF	Blink	* waste toner will fill up the box.Toner replacement is necessary. Y M C	414 415 416
HAVE YOU REPLACED * TONER? Y=ENTER/N=CANCEL	OFF	Blink	Displayed to confirm whether the user has replaced the * toner after Cover Open/Close. (This is because in case of Waster Toner Full, toner replacement cannot be automatically recognized.). The press of ENTER will reset the toner counter while clearing WASTE TONER FULL error. The press of CANCEL will bring the printer to waste toner full warning status. Y M C	
REPLACE TONER nnn: * TONER EMPTY	OFF	Blink	***** toner empty Y M C K Warning status takes effect at Cover Open/Close, while allowing printing approx 50 pages (T.B.D). (A4, density 5%).	410 411 412 413
CHECK TONER CARTRIDGE nnn:* TONER SENSOR ERROR	OFF	Blink	Something is wrong with Toner Sensor. If the Engine setting is Factory mode, error display appears as mentioned later. (This warning has appeared since PU/ FW 00.83) Y M C K	540 541 542 543
OPEN FRONT COVER nnn: PAPER SIZE ERROR	OFF	Blink	Inappropriate size paper was fed from a tray. Check the paper in the trays or check for Multiple-feed. Open and close the cover to perform recovery printing, and continue.	400
CHECK MP TRAY nnn: PAPER JAM	OFF	Blink	JAM has occurred. MP TRAY1	390
OPEN FRONT COVER nnn: PAPER JAM	OFF	Blink	JAM has occurred. TRAY1 TRAY2 FEED DUPLEX	391 392 380 372
OPEN TOP COVER nnn: PAPER JAM	OFF	Blink	JAM has occurred in paper path. Transport Exit Duplex Entry Printing Page Lost	381 382 383 389

Table 5-1-1 Operator Alarm (3/5)

Display on Operator Panel	Ready LED	Attention LED	Description	Code nnn
OPEN DUPLEX COVER nnn: PAPER JAM	OFF	Blink	JAM has occurred nearby DUPLEX unit. Duplex Reversal Duplex Input Multifeed in Duplex Unit.	370 371 373
INSTALL DUPLEX UNIT nnn: DUPLEX UNIT OPEN	OFF	Blink	Displayed if jam is occurring in Duplex Unit and the Duplex unit is removed. If a user removes the Duplex Unit when jam is not occurring in the Duplex unit, Service Call Error 181 occurs.	360
REPLACE IMAGE DRUM nnn: * DRUM LIFE	OFF	Blink	Drum life. Warning status takes effect at cover open/close. When the printer printed 500 pages (value of PU/FW 00.80. PU/FW 00.79± 20 pages), the error occurs again. Y M C K	350 351 352 353
REPLACE FUSER nnn: FUSER LIFE	OFF	Blink	Fuser life. Warning status occurs at cover open/close. When the printer printed 500 pages, the error occurs again.	354
REPLACE BELT nnn: BELT LIFE	OFF	Blink	Belt life. Warning status takes effect at cover open/close. When the printer printed 500 pages (value of PU/FW 00.80. PU/FW 00.79± 20 pages), the error occurs again.	355
REPLACE BELT nnn: BELT LIF	OFF	Blink	Water toner full. Warning status takes effect at cover open/close. When the printer printed 500 pages, the error occurs again.	356
CHECK IMAGE DRUM nnn: * DRUM MISSING	OFF	Blink	Drum is not correctly installed. Y M C	340 341 342
CHECK IMAGE DRUM & BELT LOCK nnn: K DRUM MISSING	OFF	Blink	Belt is unlocked or black drum is not correctly installed. K	343
CHECK BELT nnn: BELT MISSING	OFF	Blink	Belt unit is not correctly installed.	330
CHECK FUSER nnn: FUSER MISSING	OFF	Blink	Fuser unit is not correctly installed.	320
CLOSE COVER nnn:COVER OPEN	OFF	Blink	Cover is open. TOP (Top Cover) FRONT (Front Cover) (When either the upper or front cover is open, 310 and 311 appear in toggle because the sensor cannot identify which cover is open.)	310 311
CLOSE COVER nnn: DUPLEX COVER OPEN	OFF	Blink	Cover is open. DUPLEX	316

Table 5-1-1 Operator Alarm (4/5)

Display on Operator Panel	Ready LED	Attention LED	Description	Code nnn
DOWNLOAD MODE DATA RECEIVE	OFF	ON	Download mode when download data is received in normal operation. Show download data is receiving.	
DOWNLOAD MODE DATA RECEIVED OK			Receiving download data has finished.	
DOWNLOAD MODE REC DATA ERROR *			An error occurs when receiving download data. 1 FSize error 2 Checksum error 3 Print model No. error 4 Module I/F version error 5 FAT Version error	
DOWNLOAD MODE DATA WRITING			Download data is writing.	
DOWNLOAD MODE DATA WRITTEN OK			Writing download data has finished.	
DOWNLOAD MODE DATA WRITE ERROR			An error occurs when writing download data. 1 Memory alloc error 2 Download File error 3 Device free-space reserving error 4 Device free-space insufficient error 5 File Write error 6 CU-F/W Mismatch error	
POWER OFF/ON nnn: NETWORK ERROR			OFF	
REBOOTING d	OFF	ON	Rebooting. d: Decimal value (1 digit). Shows a cause of the rebooting. d = 0 Not listed below = 1 PjL command = 2 Changing the menu = 3 QUIT operator in PostScript language = 4 Changing the NIC setting (including from Web Page)	
POWER OFF/ON AND WAIT FOR A WHILE nnn:CONDENSING ERROR	OFF	Blink	(See the list of Service Calls.)	Fatal
POWER OFF/ON nnn: FATAL ERROR	OFF	Blink	(See the list of Service Calls.)	Fatal
SERVICE CALL nnn: FATAL ERROR	OFF	Blink	(See the list of Service Calls.)	Fatal
DOWNLOAD MODE	ON	OFF	Download Mode after the printer was powered on with pressing the Online switch. The mode that the printer to ready to receive download data.	
DOWNLOAD MODE DATA RECEIVE	Blink	OFF	Receiving download data.	

Table 5-1-1 Operator Alarm (5/5)

Display on Operator Panel	Ready LED	Attention LED	Description	Code nnn
DOWNLOAD MODE DATA RECEIVED OK	ON	OFF	Finished receiving download data.	
DOWNLOAD MODE REC DATA ERROR <No.***>	ON	ON	An error occurs when receiving download data 001 Size error 002 ChechSUM error 003 Printer model No. error 004 Module I/F version error 005 FAT Version error	
DOWNLOAD MODE DATA WRITING	Blink	OFF	Writing download data.	
DOWNLOAD MODE DATA WRITTEN OK	ON	OFF	Finished writing download data.	
DOWNLOAD MODE DATA WRITE ERROR <No.***>	ON	ON	An error occurs when writing download data 011 Memory alloc error 012 Download File error 013 Device free-space reserving error 014 Device free-space insufficient error 015 File Write error 016 CU-F/W Mismatch error	
INITIALIZING	OFF	OFF	The controller side is initializing.	
RAM CHECK\ *****	OFF	OFF	RAM checking. * appears after every 1/16 of the total amount has been checked.	

Table 5-1-2 Service Call Error (1/5)

Message	Cause	Error Description		Solution
Service call 001:Error(C5300 only)	Machine Check Exception Hardware fault detected. (Board defectiveness or Shortage of power supply volume)			Replace OWL/SPA board.
Power off/on 002:Error ~ 006:Error 007:Error(C5300 only)	CPU Exception	Does error display reappear?	Yes	Power OFF/ON Replace ARC/OWL/ SPA board.
service 020:Error	CU ROM Hash Check Error	Does error display reappear? (the case of a device which program ROM is attached to board directly.)	Yes	Power OFF/ON Replace ARC/OWL/ SPA board.
Service call 020:Error(C5300 only)	CU Program ROM Hash Check Error	Is program ROM DIMM set properly?  Is error recovered by replacing program ROM DIMM? (the case of a device which program ROM is set to DIMM Slot.)	No Yes  No	Reset ROM DIMM Replace program ROM DIMM. Replace OWL/SPA board.
Service call 023:Error(C5300 only)	CU Font ROM Hash Check Error	Does error display reappear?	Yes	Power OFF/ON Replace OWL/SPA board.
Service call 030:Error	CU RAM Check Error	Does error display reappear?	Yes	Power OFF/ON Replace ARC/OWL/ SPA board.
Service call 031:Error	CU Optional RAM Check Error	Is RAM DIMM set properly?  Is error recovered by replacing RAM DIMM?	No Yes  No	Reset RAM DIMM. Replace RAM DIMM. Replace ARC/OWL/ SPA board.
Service call 035:Error(C5300 only)	CU Optional RAM Spec Error CU RAM DIMM is not adjust to the specification.	Is RAM DIMM genuin?  Is RAM DIMM set properly?  Is error recovered by replacing RAM DIMM?	No  No Yes  No	Use genuine RAM DIMM. Reset RAM DIMM. Replace RAM DIMM. Replace OWL/SPA board.
Service call 040:Error	CU EEPROM Error	Does error display reappear?	Yes	Power OFF/ON Replace ARC/OWL/ SPA board.
Service call 041:Error	CU Flash Error Flash ROM Error on the CU board.	Does error display reappear?	Yes	Power OFF/ON Replace ARC/OWL/ SPA board.

Table 5-1-2 Service Call Error (2/5)

Message	Cause	Error Description		Solution
Service call 042:Error ~ 044:Error	Flash File System Error	Failed access to Flash set directly on CU board.		Run forced initialization of Flash.(Note that NIC- F/W and Mac address is deleted. After the initialization, it is need to download NIC-F/W and/or Mac address by Maintenance utility.) In the case of before CU-F/W G1.26/X1.26, Press "+", "-", "CAN- CEL" to turn power ON. And after CU-F/W G1.27/X1.27, execute FLASH FORMAT of MAINTENANCE MENU of SYSTEM MAINTEN- NANCE MENU. Release buttons when [FLASH FORMAT] appears, wait until [ON- LINE] (2min) and Replace ARC/OWL/ SPA board if symptom does not change.
Service call 051:Error(C5300 only)	CU Fan Error Abnormal CPU cooling fan on CU board.	Is CU Fan connector set prop- erly? Is error recovered by replacing fan?	No Yes No	Connect properly. Replace fan. Replace OWL/SPA board.
Power off/on 070:Error(C5300 only)	PSE firmware fault detected.	Does error reoccur?	Yes	Power OFF/ON. Replace OWL/SPA board.
Power off/on 072:Error xx	Engine I/F Error I/F error between PU-CU.	Is CU assembly set properly?  Is error recovered by replacing ARC/OWL board?	No Yes  No	Set properly. Replace ARC/OWL/ SPA board. Replace PU board (RSN)
Power off/on 073:Error xxxxxxxx	Video Error Fault detected when image data is extended.	[C5100] Is CU assembly set properly?  Fault again?	No Yes  Yes	Set properly. Replace to high- performance PC or drop resolution of data and print again. Replace ARC board
		[C5300] Is CU assembly set properly?	No Yes	Set properly. Replace OWL/SPA board.
Power off/on 074:Error xxxxxxxx 075:Error xxxxxxxx	Video Error Fault detected when image data is extended.	Is CU assembly set properly?	No Yes	Set properly. Replace ARC/OWL/ SPA board.

Table 5-1-2 Service Call Error (3/5)

Message	Cause	Error Description		Solution
Service call 104:Error	Engine EEPROM setting check is OK when power ON. Then detect read/ write error.	Does error reoccur?	Yes	Power OFF/ON Replace PU board (RSN)
Service call 105:Error	Read/ write error in the setting check of engine EEPROM when power on.	Does error reoccur?	Yes	Power OFF/ON Replace PU board (RSN)
Service call 106:Error	Abnormal engine control logic.	Does error reoccur?	Yes	Power OFF/ON Replace PU board (RSN)
Service call 121:Error	High-voltage power supply I/F error.	Is cable between PU board and high-voltage power unit connected properly? Is there no improperly connections?	No Yes No	Connect properly. Check improper connections for high-voltage. Replace high-voltage power supply?
Service call 122:Error	Low-voltage power supply fan error. Low-voltage power supply temperature error.	Is fan in low-voltage power supply unit operating?  Is fan connector connected properly?	No Yes No Yes	Check connections for connector of fan. Replace low-voltage power supply. Replace fan motor. Replace low-voltage power supply.
Service call 123:Error	Abnormal environment humidity / Not connected humidity sensor.	Does error reoccur?	Yes	Power OFF/ON Replace humidity sensor
Service call 124:Error	Abnormal environment temperature.	Does error reoccur?	Yes	Power OFF/ON Replace humidity sensor
Service call 127:Error	Error detected at the fuser unit cooling fan.	Is fan connector connected properly? Does error reoccur?	No Yes No	Connect properly again. Replace fan motor Replace PU board (RSN)
Service call 131:Error ~ 134:Error	LED head fault detected. (131 = Y, 132 = M, 133 = C, 134 = K)	Is LED head properly set?  Does error reoccur?	No Yes Yes	Set properly for LED head unit. Turn power ON again. Replace LED head unit
Service call 142:Error	Error detented at ID position of Up/ Down	Is ID unit set properly?  Does error reoccur?	Yes No Yes	Reset ID unit. Turn power ON again. Replace ID Up/Down sensor.
Service call 150:Error ~ 153:Error	ID unit fuse cannot be disconnected. (150 = Y, 151 = M, 152 = C, 153 = K)	Is ID unit setting proper?  Does error reoccur?  Is error recovered by replacing PRD board?	No Yes Yes  No	Reset ID unit. Turn power ON again. After check connections of cable between PRD board and PU board, replace PRD board. Replace PU board (RSN)

Table 5-1-2 Service Call Error (4/5)

Message	Cause	Error Description		Solution
Service call 154:Error	Belt unit fuse cannot be disconnected.	Is belt unit setting proper?  Does error reoccur?	No Yes Yes	Reset belt unit. Turn power ON again. Check cable connections and, replace PU board(RSN)
Service call 155:Error	Fuser unit fuse cannot be disconnected.	Is fuser unit set properly?  Does error reoccur?	No  Yes Yes	After cleaning for fuser connector, reset. Turn power ON again. Check cable connections and replace PU board (RSN)
Service call 160:Error ~ 163:Error	Error detected by toner sensor. (160 = Y, 161 = M, 162 = C, 163 = K) It does not occur in factory default setting.	Is toner cartridge setting? Is toner lock lever setting?  Does error reoccur?	No No  Yes	Set toner cartridge. Turn a lock lever of toner to a fixed position. Replace toner sensor or assembly.
Service call 170:Error 171:Error	Short circuit in fuser thermistor or open detected.	Does error reoccur?	Yes	Turn power ON again. Replace fuser unit.
Service call 172:Error 173:Error	Abnormal temperature detected by fuser thermistor (high-temp or low temp.)	Does error reoccur?	Yes	Turn power ON again. Replace fuser unit.
Service call 181:Error 182:Error	Option unit I/F error. (181 = Duplex Unit, 182 = Option Tray)	Does error reoccur?	Yes	Turn power ON again. After checking connection parts of connector, replace option unit.
Power off/on 190:Error	System Memory Overflow.	Does error reoccur?	Yes	Turn power ON again. Add option RAM DIMM.
Service call 200:Error ~ 202:Error	PU Firmware download Error.	Error occurred while writing over the PU firmware.		Turn the printer OFF/ON, and retry to download the PU firmware again. (Usually, the procedure (PU firmware download) which isn't done, so this is not occur.)
Power off/on 209:Download Error	Media Table download Error.	Downloading Media Table to PU has failure.(Related to Custom Media Type)		Turn the printer OFF/ON, and retry to download the PU firmware, again. (Usually, the procedure isn't done, so this is not occur.)

Table 5-1-2 Service Call Error (5/5)

Message	Cause	Error Description		Solution
Power off/on 203:Error 204:Error 207:Error 208:Error 210:Error ~ 214:Error F0C:Error F0D:Error(C5300 only) FFE:Error(C5300 only) FFF:Error	An error was detected of the CU program. (203~214 is not occur in usual operating.)	Reinstall the CU board. Is the error message displayed again?		After turn power OFF, check connections between CU board and PU board. Then turn power ON again.
Service call 220:Error	False setting of a record medium detected by a print statistics.	Take off the HDD or replaced?	Yes	Reset original HDD.
Power off/on 901:Error 902:Error	Short or open in belt thermistor detected.	Is belt thermistor cable setting proper?  Does error reoccur?	No Yes Yes	Connect cable set properly again. Turn power ON again. Replace belt thermistor.
Power off/on 903:Error 904:Error	Abnormal temperature detected by belt thermistor (high-temp or low temp.)	Is belt thermistor cable setting proper?  Does error reoccur?	No Yes Yes	Connect cable set properly again. Turn power ON again. Replace belt thermistor and leave aside for 30 min. Then turn power ON again.

5.5.2 Preparing for troubleshooting

(1) Operator panel display


Problems that are generated in this device are indicated in the LCD.

Apply proper measures according to the message displayed in the LCD.

No.	Problem	Flow Chart No.
1	Printer Malfunction after Turn-on.	①
2	Jam Errors Paper Loading Jam (1st tray) Paper Loading Jam (Multipurpose tray) Paper Feed Jam Paper Exit Jam Duplex Print Jam	②-1 ②-2 ②-3 ②-4 ②-5
3	Paper Size Error	③
4	Image Drum Up/Down Operation Error	④
5	Fuser Unit Error	⑤
6	Motor Fan Error	⑥

**Note:** When replacing engine boards (RSN PWBs), read in the EEPROM chip data from the boards and copy it onto installed new boards.


Is an error message displayed?




## ① The printer does not operate properly after it is turned on.

- Turn the printer off and on again.
- Does ■■■■■■■■■■■■ appear (for about one second)?
  - NO Is the AC cable connected properly?
    - NO Connect the AC cable properly.
  - YES Is +5V being output to the operator panel connector (OPE connector) on the engine board (RSN PWB)?
    - Pin 4: +5V. Pin 7: 0V.
    - YES Is +5V being output to the connector CN1 on the OPE board (RSP PWB)?
      - Pin 4: +5V. Pin 7: 0V.
      - NO Is the operator panel cable connected properly?
        - NO Connect the cable properly.
        - YES Replace the operator panel cable. Has the printer recovered from the error?
          - NO Replace the OPE board.
          - YES End.
    - NO Is +5V being output to the POWER connector on the engine board (RSN PWB)?
      - Pins 7 to 9: +5V. Pins 1 to 3, and 13 to 17: 0V.
      - NO Replace the low voltage power unit after checking the connection of the POWER connector.
      - YES Replace the engine board.
  - YES Are the following voltages being output to the CU board PUIF connector?
    - Pins 7 and 8: +5V. Pins 4 and 5: +3.3V. Pins 1, 2, 3 and 6: 0V.
    - YES Replace the CU Board.
  - NO Are the following voltages being output to the POWER connector on the engine board?
    - Pins 7 to 9: +5V. Pins 10 to 12: +3.3V. Pins 4 to 6: +24V. Pins 1 to 3, and 13 to 17: 0V.
    - YES Replace the engine board.
    - NO Replace the low voltage power unit.


## ②-1 Paper Loading Jam (1st tray)




## ②-2 Paper Loading Jam (Multipurpose tray)




## ②-3 Paper Feed Jam



## ②-4 Paper Exit Jam



## ②-5 Duplex Print Jam



## ③ Paper Size Error

• Is proper size paper being used?

NO Use proper size paper.

▼  
• YES Is paper jammed at the entrance sensor 2?

YES Remove the jammed paper.

▼  
• NO Does the lever of the entrance sensor 2 move properly?

NO Replace the lever.

▼  
• YES Does the entrance sensor 2 work properly? (Operate the entrance sensor lever to check the signal on a corresponding FSNS connector pin on the engine board RSN PWB.)  
Pin 2: Entrance sensor 2

NO Replace the sensor board (RSF PWB) after checking cable connection.

▼  
• YES Does the lever of the write sensor move properly?

NO Replace the lever.

▼  
• YES Does the write sensor work properly? (Operate the write sensor lever to check, through the switch scan test of System Maintenance mode, the sensor for proper operation. The signal on a corresponding FSNS connector pin of the engine board (RSN PWB) is to be checked.)  
Pin 3: Entrance write sensor

NO Replace the sensor board (RSF PWB) after checking cable connection.

▼  
• YES Replace the engine board after checking cable connection.

## ④ Image Drum Unit (ID) Up/Down Operation Error

- Power the printer off and, after a few seconds, on again.
- Are all the ID drums properly revolving during printing?
  - NO Does the ID motor (C) have a rated resistance (approx.  $3.5\Omega$ )?
    - NO Replace the ID motor(C).
  - YES Is 24V being output to the F1 of the engine board?
    - NO Replace the low voltage power unit.
  - YES Replace the engine board after checking cable connection.
- YES Is ID up-and-down operation being performed (is the operation performed by ID UP/DOWN on motor and clutch testing)?
  - NO Replace the gear assys - planet L and R.
- YES Does the ID up/down sensor work properly? (Check the signals on the high voltage power unit CN3, pin 2.)
  - Are: 5V with the sensor light unshielded; and  
0V with sensor light shielded  
being output?
  - NO Replace the high voltage power unit.
- YES Replace the engine board after checking the cable connection between the high voltage power unit and the engine board (RSN PWB)

⑤ Fuser Unit Error






Figure 5.1


## ⑥ Motor Fan Error




5.5.3 Image Problem Troubleshooting

When printout images are not satisfactory as illustrated below, follow the troubleshooting steps listed below.


Abnormal Image	Flowchart No.
Light or faded image, or color misalignment, on whole page (Figure 5.2- <b>A</b> )	①
Dirty background (Figure 5.2- <b>B</b> )	②
Blank page (Figure 5.2- <b>C</b> )	③
Vertical belt or line (black or color) (Figure 5.2- <b>D</b> )	④
Vertical belt or line (white or uneven-color) (Figure 5.2- <b>E</b> )	⑤
Poor fusing (ink spreads or peels when touched with fingers.)	⑥
Defective image of regular interval (Figure 5.2- <b>F</b> )	⑦
Missing image	⑧
Color misalignment	⑨
Color different from original one	⑩




**A** Light or faded image on whole page




**B** Dirty Background




**C** Blank



**D** Vertical black belt or line




**E** Defective image of regular interval



**F** Vertical white belt or line


Figure 5.2

## ① Light or faded image, or color misalignment, on whole page (Fig 5-2 (A))




**Note:** When replacing the engine board (RSN PWB), extract EEPROM data from it and copy the data onto a new engine board.

## ② Dirty background (Fig. 5-2 ㉞)




**Note:** When replacing the engine board (RSN PWB), extract EEPROM data from it and copy the data onto a new engine board.

## ③ Blank page (Fig 5-2 ©)



**Note:** When replacing the engine board (RSN PWB), extract EEPROM data from it and copy the data onto a new engine board.

## ④ Vertical belt or line (black or color) (Fig. 5-2 ㉔)



**Note:** When replacing the engine board (RSN PWB), extract EEPROM data from it and copy the data onto a new engine board.

## ⑤ Vertical belt or line (white or uneven-color) (Fig. 5-2 ㊦)

- Are the LED heads dirty?
  - YES Clean dirty LED head(s).
- ▼ NO Are the image drum pins connected to the contact assy properly (see figure 5-3 D)?
  - NO Connect not properly connected pin(s) to the contact assy correctly.
- ▼ YES Replace the image drum units.
- Are the LED head assys connected to the CU board (ARC PWB / OWL PWB / SPA PWB) properly?
  - NO Connect not properly connected LED head assy(s) to the CU board (ARC PWB / OWL PWB / SPA PWB) correctly.
- ▼ YES Replace LED head assys after checking cable connection. Has the problem been corrected?
  - YES End.
- ▼ NO Replace the high voltage belt unit. Has the problem been corrected?
  - YES End.
- ▼ NO Replace the connection board (Y73 PWB) after checking cable connection. Has the problem been resolved?
  - YES End.
- ▼ NO Is the I/D terminal connected properly to the contact assembly? (See Fig. 5-3)
  - NO Is the engine board (RSN PWB) connected to the CU board properly?
- ▼ YES Replace the engine board (RSN PWB) after checking cable connection. Has the problem been corrected?
  - YES End.

**Note:** When replacing the engine board (RSN PWB), extract EEPROM data from it and copy the data onto a new engine board.

## ⑥ Poor fusing (Ink spreads or peels when touched lightly with fingers.)

- Is proper paper being used?
  - NO Use proper paper.
- ▼ YES Are the contact of the fuser unit connected properly?
  - NO Connect the contact of the fuser unit properly.
- ▼ YES Are the rollers of the fuser unit dirty?
  - YES Replace the fuser unit.
- ▼ NO Is MEDIA WEIGHT (menu 1) set properly?  
 LIGHT: 64 to 74 g/m<sup>2</sup>. MEDIUM: 75 to 104 g/m<sup>2</sup>. HEAVY: 105 to 120 g/m<sup>2</sup>.  
 ULTRAHEAVY: 121 to 203 g/m<sup>2</sup>. TRANSPARENCY.
  - NO Set the MEDIA WEIGHT correctly.
- ▼ YES Is AC voltage being output between the CN2 connector pins 1 and 3 of the low voltage power unit?
  - NO Replace the low voltage power unit.
- ▼ YES Does the heat roller thermistor have a rated resistance (approx. 180 k to 980 kΩ at room temperatures of 0 to 43°C) (see figure 5-1)?
  - NO Replace the fuser unit.
- ▼ YES Does the fuser temperature agree with its specification? Check the fuser temperature on the LCD display of Engine Maintenance mode.  
 Heat Roller: 145 to 155°C  
 155 to 174°C (when MEDIA WEIGHT is set to LIGHT)
  - NO Replace the fuser unit.
- ▼ YES Replace the fuser unit.


**Note:** When replacing the engine board (RSN PWB), extract EEPROM data from it and copy the data onto a new engine board.

## ⑦ Defective image of regular interval (Figure 5.2-⑤)

Interval	Problem	Troubleshooting
94.2 mm	Image Drum	Replace the image drum unit.
50.24 mm	Developing Roller	Replace the image drum unit.
47.10 mm	Toner Supply Roller	Replace the image drum unit.
37.68 mm	Charging Roller	Replace the image drum unit.
85.41 mm	Fuser Upper Roller	Replace the fuser unit.
87.92mm	Fuser Lower Roller	Replace the fuser unit.
50.24mm	Transfer Roller (K)	Replace the belt unit.
43.96mm	Transfer Roller (Color)	Replace the belt unit.

**Note:** The life counts of the image drum units, fuser unit and belt unit are automatically reset at their respective replacements.

## ⑧ Missing image



**Note:** When replacing the engine board (RSN PWB), extract EEPROM data from it and copy the data onto a new engine board.

## ⑨ Color misalignment

“TONER LOW” is showing on the display.

YES Supply toner. Has the problem been resolved?

YES End.

NO Conduct a color registration test of Engine Maintenance mode.  
Procedure: Enter the self-diagnostic mode (level 1) of Engine maintenance mode.

DIAGNOSTIC MODE
XX.XX.XX

Pressing the MENU+ or MENU- key three times displays “REG ADJUST TEST.”

REG ADJUST TEST

Press the ENTER key once to show “REG ADJUST EXECUTE.”

REG ADJUST EXECUTE

Press the ENTER key to execute auto color registration adjustment (the motor starts running and color registration adjustment is performed).


Has the symptom that the color registration adjustment operation is not performed (the motor does not run) and “OK” is immediately displayed occurred?

YES An other-than-color-misalignment error occurred. Correct the error. Has the color misalignment resolved?

YES End.

(A)

(A)




(B)

(B)

- [Is “YELLOW/MAGENTA/CYAN LEFT/RIGHT/HORIZONTAL” displayed?
  - YES Replace the belt unit. Has the problem been corrected?
    - YES End.
  - ▼ NO Replace the image drum unit. Has the problem been resolved?
    - YES End.
  - ▼ NO Are there any problems in the gear assys of the image drums, multipurpose tray, belt unit, belt motor etc.?  
 YES Replace damaged gear assy(s).
  - ▼ NO Replace the driver board. Has the problem been corrected?
    - YES End.
  - ▼ NO Are the LED head units connected to the CU board (ARC PWB / OWL PWB / SPA PWB) properly?  
 NO Connect not properly connected LED head unit(s) to the connection board correctly.
  - ▼ YES Replace the LED head assys after checking cable connection. Has the problem been resolved?
    - YES End.
  - ▼ NO Replace the CU board (ARC PWB / OWL PWB / SPA PWB) after checking cable connection. Has the problem been corrected?
    - YES End.
  - ▼ NO Is the engine board (RSN PWB) connected to the CU board (ARC PWB / OWL PWB / SPA PWB) properly?  
 NO Connect the engine board to the connection board correctly.
  - ▼ NO Replace the engine board. Has the problem been resolved?
    - YES End.
  - ▼ NO Are the pins of the image drum units connected to the contact assy properly (see figure 5-3)?  
 NO Connect not properly connected pins to the contact assy correctly.
  - ▼ YES Replace the image drum units.

**Note:** When replacing the engine board (RSN PWB), extract EEPROM data from it and copy the data onto a new engine board.

## ⑩ Color different from original one



**Note:** When replacing the engine board (RSN PWB), extract EEPROM data from it and copy the data onto a new engine board.




Figure 5.3

#### 5.5.4 Actions Taken after Forced HDD/Flash Initialization

This section describes actions taken after forced HDD or Flash initialization in the event of problems in HDDs or Flash.

- 1) **Actions after Forced HDD Initialization**  
 Forced HDD initialization erases the following data. There are no data recovery methods.
  - Internal not-yet-printed data
  - JobAccount log data (when JobAccount has been activated)
  
- 2) **Actions after Forced Flash Initialization**  
 Forced Flash initialization erases the following data, causing network inoperability.
  - NIC firmware
  - Mac addresses
  - Web page data
  - OEM-oriented demonstration page data (in printers to OEM purchasers)

Using maintenance utility software, Flash must be programmed with the above NIC-firmware, Mac addresses and Web page data.

## 5.6 Fuse Checking







When the following errors occur, that fuse on the high voltage board which is associated with each error is to be checked (see table 5-6).







Table 5-6 Fuse Error







Fuse Name		Error Description	Insert Point
Engine Board (RSN PWB)	F1	M or C toner sensor error	M-ID and C-ID motor 24V
	F2	K toner sensor error	Hop and K-ID motor 24V
	F3	Cover open error	High voltage, fan, Ver and Y-ID 24V
	F4	2nd tray or duplex unit paper jam	2nd tray and duplex 24V
	F5	Paper jam during printing	Belt fuser motor 24V
	F6	No operator panel display	5V sensor system
High Voltage Board	IP102	Cover open error	High voltage 24V



## 6. CONNECTION DIAGRAM

### 6.1 Resistance Checks

Unit	Circuit Diagram	Illustration	Resistance
Transport Belt Motor			<p>Between pins 1 and 2: 3.5Ω                      Between pins 3 and 4: 3.5Ω</p>
Main Motor (Y)			<p>Between pins 1 and 2: 6.0Ω                      Between pins 3 and 4: 6.0Ω</p>
Main Motor (M)			<p>Between pins 1 and 2: 6.0Ω                      Between pins 3 and 4: 6.0Ω</p>


Unit	Circuit Diagram	Illustration	Resistance
Main Motor (C)			<p>Between pins 1 and 2: 6.0Ω                      Between pins 3 and 4: 6.0Ω</p>
Main Motor (K)			<p>Between pins 1 and 2: 6.0Ω                      Between pins 3 and 4: 6.0Ω</p>
Fuser Motor			<p>Between pins 1 and 2: 6.0Ω                      Between pins 3 and 4: 6.0Ω</p>

Unit	Circuit Diagram	Illustration	Resistance
Feeder Motor			Between pins 1 and 2: 3.5Ω Between pins 3 and 4: 3.5Ω
Duplex Motor			Between pins 1 and 2: 3.5Ω Between pins 3 and 4: 3.5Ω
2nd tray Feeder Motor			Between pins 1 and 2: 3.5Ω Between pins 3 and 4: 3.5Ω

Unit	Circuit Diagram	Illustration	Resistance
Fuser Unit	 <p>① Upper roller a ○</p> <p>Heater</p> <p>Thermostat ① b ○</p> <p>Thermistor c ○</p> <p>d ○</p> <p>e ○</p> <p>f ○</p>		<p>1. Upper Roller Side Between pins "a" and "b": Between pins "c" and "d": 363k Ω (at 25°C) Between pins "e" and "f": Open</p>


## 6.2 Program/Font ROM Layouts

### (1) Print Engine Controller PWB (RSN-1 PWB)




(2) Main Controller PWB (OWL PWB) (For C5300)

Serial No. ... "nnnAxxxxxx"




(3) Main Controller PWB (SPA PWB) (For C5300VE version)


Serial No. ... "nnnBxxxxxx"




(4) Main Controller PWB (ARC PWB) (For C5100)




(5) Driver PWB (RSM PWB)



(6) Duplex Controller PWB (V7X PWB)




(7) Control Panel PWB (RSP PWB)




(8) Toner Low Sensor PWB (PRD-PWB)




(9) Entrance Sensor PWB (RSF PWB)



(10) High voltage power supply PWB



(11) Low voltage power supply PWB



## 7. PARTS LIST

C5300




Figure 7-1-1 Parts Layout (C5300)

C5100




Figure 7-1-2 Parts Layout (C5100)

Table 7-1 (1/3)

## Parts\_Layout

No.	Parts No.	Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks
				per 500	per 1000	per 2000	
1	42074501	Top Cover Assy	1	2	4	8	
2	42067501	Control Panel Assy	1	2	4	8	ODA/AOS
	42067502	Control Panel Assy	1	2	4	8	OEL
3	42127415	Toner-C	1	-	-	-	Packed in box.
	42127403	Toner-C (ODA)	1	-	-	-	Packed in box.
	42127407	Toner-C (OEL)	1	-	-	-	Packed in box.
	42127411	Toner-C (AOS)	1	-	-	-	Packed in box.
4	42127414	Toner-M	1	-	-	-	Packed in box.
	42127402	Toner-M (ODA)	1	-	-	-	Packed in box.
	42127406	Toner-M (OEL)	1	-	-	-	Packed in box.
	42127410	Toner-M (AOS)	1	-	-	-	Packed in box.
5	42127413	Toner-Y	1	-	-	-	Packed in box.
	42127401	Toner-Y (ODA)	1	-	-	-	Packed in box.
	42127405	Toner-Y (OEL)	1	-	-	-	Packed in box.
	42127409	Toner-Y (AOS)	1	-	-	-	Packed in box.
6	42127416	Toner-K	1	-	-	-	Packed in box.
	42127404	Toner-K (ODA)	1	-	-	-	Packed in box.
	42127408	Toner-K (OEL)	1	-	-	-	Packed in box.
	42127412	Toner-K (AOS)	1	-	-	-	Packed in box.
7	42126615	ID-C	1	-	-	-	Packed in box.
	42126603	ID-C (ODA)	1	-	-	-	Packed in box.
	42126607	ID-C (OEL)	1	-	-	-	Packed in box.
	42126611	ID-C (AOS)	1	-	-	-	Packed in box.
8	42126614	ID-M	1	-	-	-	Packed in box.
	42126602	ID-M (ODA)	1	-	-	-	Packed in box.
	42126606	ID-M (OEL)	1	-	-	-	Packed in box.
	42126610	ID-M (AOS)	1	-	-	-	Packed in box.
9	42126613	ID-Y	1	-	-	-	Packed in box.
	42126601	ID-Y (ODA)	1	-	-	-	Packed in box.
	42126605	ID-Y (OEL)	1	-	-	-	Packed in box.
	42126609	ID-Y (AOS)	1	-	-	-	Packed in box.
10	42126616	ID-K	1	-	-	-	Packed in box.
	42126604	ID-K (ODA)	1	-	-	-	Packed in box.
	42126608	ID-K (OEL)	1	-	-	-	Packed in box.
	42126612	ID-K (AOS)	1	-	-	-	Packed in box.
11	42158704	Belt-Unit	1	-	-	-	Packed in box.
	42158701	Belt-Unit (ODA)	1	-	-	-	Packed in box.
	42158702	Belt-Unit (OEL)	1	-	-	-	Packed in box.
	42158703	Belt-Unit (AOS)	1	-	-	-	Packed in box.
12	42135601	Board-RSM	1	2	4	8	
13	42065101	Sensor-Assy-Color-Regist	1	2	4	8	

Table 7-1 (2/3)

## Parts\_Layout

No.	Parts No.	Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks
				per 500	per 1000	per 2000	
14	42066901	Cover-Driver	1	1	2	4	
15	42079601	Cover-Assy-SideR	1	2	4	8	
16	42294101	Plate-Assy-Shield (GDI)	1	2	4	8	C5100
	42079101	Plate-Assy-Shield (PCL)	1	1	2	4	C5300
17	42135501	Print Engine Controller PWB	1	1	2	4	Board PU
18	42141601	CONN Cord	1	1	2	4	PU-CU C5100
19	42373501	Controler Board CU (GDI) (ARC PWB)	1	1	2	4	Board CU C5100
	42373401	Controler Board CU (PCL) (OWL PWB)	1	2	4	8	Board CU C5300
	42493401	Controler Board CU (PCL) (SPA PWB)	1	2	4	8	Board CU C5300VE ECO-C5300-012
20	42078701	Film-Insulation	1	2	4	8	
21	42053501	Plate-Assy-Side-R	1	3	6	12	
22							
23	42063001	Eject-Assy	1	1	2	4	
24	42158605	Fuser-Unit	1	-	-	-	Packed in box.
	42158601	Fuser-Unit (ODA 120V)	1	-	-	-	Packed in box.
	42158602	Fuser-Unit (ODA 230V)	1	-	-	-	Packed in box.
	42158603	Fuser-Unit (OEL)	1	-	-	-	Packed in box.
	42158604	Fuser-Unit (AOS)	1	-	-	-	Packed in box.
25	42049501	Base-Assy	1	2	4	8	
26	42060001	Plate-Assy-Side-L	1	2	4	8	SA9-1125
27	41978801	Power Unit High Voltage	1	2	4	8	
28	42465401	Cover-SideL	1	1	2	4	SA9-1287
	42465402	Cover-SideL	1	1	2	4	
29	42087001	Cassette Assy	1	1	2	4	
30	42061501	Cover Assy-Hopping	1	2	4	8	
31	42069001	Feeder-Unit	1	2	4	8	
32	42062101	Plate-Driver	1	1	2	4	
33	42062401	Gear-Idle-Belt	1	1	2	4	
34	42088801	Friction Pad Assy	1	3	6	12	SA9-1332 Color silver gray → white
35	42089001	Friction Pad Assy-Springs	1	3	6	12	
36	42078301	Cover Assy Face Up	1	1	2	4	
37	42077601	Cover Sub Assy Rear	1	1	2	4	
38	42143101	LED HEAD Unit 51MXE	4	2	4	8	600DPI
39	42489901	Electrical Cooling FAN (80)	1	1	2	4	Fuser SA9-1247
	42396101	Electrical Cooling FAN (80)	1	1	2	4	Fuser SA9-1238
40	42295501	Electrical Cooling FAN (ID)	1	1	2	4	
41	42295401	Frame Duct	1	1	2	4	
42	41992701	Power Unit (LOW Voltage)	1	2	4	8	100-120V
	42408601	Power Unit (LOW Voltage)	1	2	4	8	230V

Table 7-1 (3/3)

## Parts\_Layout

No.	Parts No.	Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks
				per 500	per 1000	per 2000	
43	2381031P0003	TW VF 19-01X06-460	1	2	4	8	FFC High Volt.
44	42067001	Spring Belt Fuse	2	1	2	4	
45	42303301	Thermistor	1	2	4	8	
46	42066001	Shaft Lift Up	1	1	2	4	
47	42067101	Plate Heart	1	1	2	4	
48	40135301	Photo Interrupter	1	1	2	4	
49	42141103	CONN CORD AMP3P-AMP3P	1	2	4	8	ID Up/Down
50	42076901	Spring Torsion (L)	1	1	2	4	
51	42077001	Spring Torsion (R)	1	1	2	4	
52	42063701	Gear Assy Planet	1	2	4	8	
53	42064101	Gear Idle Heat (Z14-102)	1	2	4	8	
54	42066501	Gear Assy Planet L	1	2	4	8	
55	42134901	Plate Shield CU (GDI)	1	1	2	4	C5100
	42078801	Plate Shield CU (PCL)	1	1	2	4	C5300
56	42076502	Plate-Logo	1	-	-	-	C5100
	42076501	Plate-Logo	1	-	-	-	C5100
	42076504	Plate-Logo	1	-	-	-	C5300
	42076503	Plate-Logo	1	-	-	-	C5300
57	42343002	ROM DIMM	1	-	-	-	C5300
	42343001	ROM DIMM	1	-	-	-	C5300
	42010602	ROM DIMM (P-ROM) for OWL PWB	1	-	-	-	C5300 (Ver X1.35)
	42010502	ROM DIMM (Flash) for OWL PWB	1	-	-	-	C5300
	42010606	ROM DIMM (P-ROM) for SPA PWB	1	-	-	-	C5300VE (Ver X2.12)
	42010506	ROM DIMM (Flash) for SPA PWB	1	-	-	-	C5300VE
58	42078901	Plate FG Connector (PCL)	1	1	2	4	C5300
59	42561901	Maintenance kit for C5100/5300	1	1	2	4	Except for CN-5100-011 Affected Printers

**Note:** ROM DIMM (P-ROM) is not re-writable.  
ROM DIMM (Flash) is re-writable, but high-price.  
The newest firm-ware is written to ROM DIMM (Flash) at the time of factory shipments.




Figure 7-2 Top\_Cover\_Assy

Table 7-2

## Top\_Cover\_Assy

No.	Parts No.	Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks
				per 500	per 1000	per 2000	
1	42074601	Plate-Inner (Caulking)	1	1	2	4	
2	42075001	Holder-Head	4	1	2	4	
3	42075101	Spring-Head	8	1	2	4	
4	42075301	Plate-FG-Head	8	1	2	4	
5	42075501	Cable-Assy.-Head	1	2	4	8	
6	42076201	Cover-Cable	1	1	2	4	
7	42076301	Cover-Ass.-Top (Sub)	1	1	2	4	
8	42076601	Roller Assy.-Idle (FD)	2	2	4	8	
9	42373601	Holder-SP (Inner)	1	1	2	4	SP7-1352
10	42392501	Spring-Compression (ID)	4	1	2	4	
11	4PB4083-2500P008	Tapping Screw B2	10	-	-	-	
12	4PB4013-3100P006	Cup Screw A	1	-	-	-	
13	42076401	Top Cover	1	1	2	4	
14	42115701	Cover Top Sub	1	1	2	4	
15	42293101	Spring Torsion (Sub)	2	1	2	4	
16	42075601	LED Harness K	1	2	4	8	
17	42075701	LED Harness Y	1	2	4	8	
18	42075801	LED Harness M	1	2	4	8	
19	42075901	LED Harness C	1	2	4	8	
20	42076101	Film FG	1	1	2	4	




Figure 7-3 Frame\_Assy-OP

Table 7-3

## Frame\_Assy-OP

No.	Parts No.	Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks
				per 500	per 1000	per 2000	
1	42067601	Plate-Front	1	1	2	4	
2	42067701	Lever-Lock (Top)	1	1	2	4	
3	42067801	Spring-Compression (Lock)	1	1	2	4	
4	42067901	Frame-OP panel	1	1	2	4	
5	42068001	Cover-Assy. -OP	1	2	4	8	
6	42293201	Spring-Torsion (FG)	2	1	2	4	
7	5602002P0001	SENSOR-Temp	1	1	2	4	
8	42141703	CONN CORD JST4P-JST4P	1	1	2	4	OP-Temp
9	42068403	Control Panel Sheet	1	1	2	4	Domestic
	42068401	Control Panel Sheet	1	1	2	4	ODA
	42068402	Control Panel Sheet	1	1	2	4	OEL/AOS
10	42290901	Board RSP	1	2	4	8	Control Panel
11	2381031P0001	TW VF 8-01X06-230	1	1	2	4	FFC Control Panel
12	42068101	Cover-OP-Panel	1	1	2	4	




Figure 7-4 Feeder\_Unit

Table 7-4

## Feeder\_Unit

No.	Parts No.	Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks
				per 500	per 1000	per 2000	
1	42069201	Cover Assy-Front	1	1	2	4	
2	42069601	Lever-Release-F	1	1	2	4	
3	42070001	Guide-Assy-Top	1	1	2	4	
4	42070501	Feeder-Assy-Resist	1	2	4	8	
5	42072201	Gear-Puressure	1	2	4	8	
6	42072401	Gear-Regist-L (24-54)	1	2	4	8	
7	42057601	Gear-Z42	1	2	4	8	
8	42072501	Gear-Idle-MPT (26-50)	1	2	4	8	
9	42072701	Post-Slide	2	1	2	4	
10	42072801	Spring-Release-F	2	1	2	4	
11	42074001	Stay-Front-L	1	1	2	4	
12	42074101	Stay-Front-R	1	1	2	4	
13	4PB4083-2500P008	Tapping Screw B2	7	1	2	4	
14	42070301	Shaft Assy MPT	1	3	6	12	
15	42299701	Roller Guide	1	1	2	4	
16	42069901	Spring Separator	1	3	6	12	
17	42069701	Frame Separator	1	3	6	12	
18	42070101	Guide Sheet Top	1	1	2	4	
19	3263103K0107	MRH100MK	1	1	2	4	
20	42135801	Board RSF	1	2	4	8	
21	42141001	CONN Cord JST5P-JST5P	1	2	4	8	RSF-PU
22	42072901	MPT Cover Assy	1	2	4	8	




Figure 7-5 Cover\_Assy-Hopping

Table 7-5

## Cover\_Assy-Hopping

No.	Parts No.	Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks
				per 500	per 1000	per 2000	
1	42061601	Cover Hopping	1	1	2	4	
2	2233013P0110	Connector (9715B-11Z02)	1	2	4	8	
3	PB4083-2500P008	TAPPING SCREW B2	1	-	-	-	
4	42141201	CONN Cord	1	1	2	4	Dup-PU




Figure 7-6 Plate\_Assy-Side\_R

Table 7-6

## Plate\_Assy-Side\_R

No.	Parts No.	Name	Q'ty /Unit	Recommended Qty/Year			Remarks
				per 500	per 1000	per 2000	
1	42053801	Plate-Side-R (Caulking)	1	1	2	4	
2	42054501	Motor-Pulse-ID (K)	4	2	4	8	
3	42054801	Motor-Pulse-Fuser	1	2	4	8	
4	42054901	Guide Assy-Side-R	1	1	2	4	
5	42055501	Link-Liftup-R	1	2	4	8	
6	42055701	Gear-Planet	1	2	4	8	
7	42055901	Gear Assy-Planet-R	1	2	4	8	
8	42057101	Gear-Idle-Liftup	1	2	4	8	
9	42055101	Cover-Plate-R	1	1	2	4	
10	2381031P0002	TW-VF-11-01X06-80	1	2	4	8	PRD-PU
11	42057301	Gear Assy-HP	1	2	4	8	
12	42058201	Motor-Resist	1	2	4	8	
13	42058303	Solenoid	1	2	4	8	SA9-1121
14	42058401	Spring-Solenoid	1	1	2	4	
15	42293401	Guide Assy-Cable-F	1	2	4	8	
16							
17	42058601	Bracket-Inner (Caulking)	1	1	2	4	
18	42059001	Gear-Idle-Drum-K	1	2	4	8	
19	42059101	Gear-Idle-Drum-M	1	2	4	8	
20	42059201	Gear-Idle-Drum-YC	2	2	4	8	
21	42059301	Bracket-Outer	1	1	2	4	
22							
23	4PB4013-3100P006	Cup Screw A	13	-	-	-	
24	4PB4083-2500P008	Tapping Screw B2	4	-	-	-	
25	42437301	Plate-Lockout-ID	1	1	2	4	SA9-0971
26	PSW3-4C	Screw	1	-	-	-	SA9-0992
27	RE3-SK	Ring	1	-	-	-	
28	RE4-SK	Ring	2	-	-	-	
29	42135701	Board-PRD	1	2	4	8	
30	42055201	Spring-Contact-TL	9	1	2	4	
31	42141401	CONN Cord-JST12P-JST4PX3	1	2	4	8	PU-Y.M.C motor
32	42141501	CONN Cord-JST26P-JST26P	1	2	4	8	PU-RSM
33	42303501	CONN Cord-JST2P-JST2P	1	2	4	8	PU-BELT Thermistor
34	42141301	CONN Cord-JST8P-JST4PX2	1	2	4	8	PU-HOP, K motor
35	42058501	Guide-Cable F	1	1	2	4	
36	RE2-SK	Ring	1	-	-	-	SA9-1237




Figure 7-7 Plate\_Assy-Side\_L

Table 7-7

## Plate\_Assy-Side\_L

No.	Parts No.	Name	Q'ty /Unit	Recommended Qty/Year			Remarks
				per 500	per 1000	per 2000	
1	42060101	Plate-Side-L (Caulking)	1	1	2	4	
2	42054601	Motor-Pulse-ID-Belt	1	2	4	8	
3	42141701	CONN Cord-JST4P-JST4P	1	2	4	8	
4	42060401	Contact-Assy	1	2	4	8	
5	42060701	Bush	1	1	2	4	
6	42060801	Link-Liftup-L	1	2	4	8	
7	42055701	Gear-Planet	1	2	4	8	
8	42060901	Guide Assy-Side-L	1	2	4	8	
9							
10	4PB4013-3100P006	Cup Screw A	1	-	-	-	
11	42025701	Micro switch-Assy	1	2	4	8	
12	RE3-SK	Ring	1	-	-	-	

C5300




Figure 7-8-1 Plate\_Assy-Shield (C5300)

C5100




Figure 7-8-2 Plate\_Assy-Shield (C5100)

Table 7-8

## Plate\_Assy-Shield

No.	Parts No.	Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks
				per 500	per 1000	per 2000	
1	42466301	Plate-Side (PCL)	1	1	2	4	C5300
	42466401	Plate-Side (GDI)	1	1	2	4	SA9-1130 C5100
2	42079301	Plate_Contact-Shield	3	1	2	4	
3	41410201	Electrical Cooling FAN (60)	1	1	2	4	CU Board




Figure 7-9 Sensor\_Assy-Regist

Table 7-9

## Sensor\_Assy-Color\_Regist

No.	Parts No.	Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks
				per 500	per 1000	per 2000	
1	42065201	Plate-Sensor-C Regist	1	1	2	4	
2	41258601	Board-Z71	1	3	6	12	Color Regist
3	5654200P0001	GP2TCS SENSOR-Density	1	3	6	12	Density
4	42220901	Plate_Guard-sensor	2	1	2	4	
5	42141801	CONN Cord-JST14P MOLEX5PJST4PX2	1	2	4	8	RSM-Color Registration and Density SNSs
6	42065301	Cover-C.Resist (Adhesive)	1	1	2	4	
7	42065701	Gear-Cover-Sensor (Rack)	1	2	4	8	
8	42065801	Shaft-Cover-Sensor	1	2	4	8	
9	42065901	Spring-Cover-Sensor	1	1	2	4	
10	4PB4013-3100P006	Cup Screw A	3	-	-	-	




Figure 7-10 Plate Ass'y-Base

Table 7-10

## Plate\_Assy-Base

No.	Parts No.	Name	Q'ty /Unit	Recommended Qty/Year			Remarks
				per 500	per 1000	per 2000	
1	42049601	Plate-Base	1	1	2	4	
2	42049701	Guide Assy.-Cassette-L	1	1	2	4	
3	42050101	Guide Assy.-Cassette-R	1	1	2	4	
4	42050301	Plate-Beam	1	1	2	4	
5	42050401	Lever-End	1	1	2	4	
6	40135301	Photo-Interrupter	1	2	4	8	SNS-END
7	42141101	CONN Cord-AMP3P-AMP3P	1	2	4	8	PU-P-END
8	4YC4061-1026P001	Tape	1	-	-	-	L=30mm
9	42050701	Shaft-Hopping	1	1	2	4	
10	42050801	Stopper-HP	1	2	4	8	
11	42050901	Holder-Planet-HP	1	2	4	8	
12	42051001	Gear-Planet (Z12)-HP	2	2	4	8	
13	42051101	Gear-Z24-50-HP	1	2	4	8	
14	42051201	Stopper-Z45-48-HP	1	2	4	8	
15	42051401	Bracket-Assy.-Sub	1	2	4	8	
16	41513401	Bearing-Metal	1	1	2	4	
17	4PP4083-6022P002	BEARING A	1	1	2	4	
18	42052301	Gear-Hopping (Z38)-HP	1	2	4	8	
19	42052501	Spring-Sub	1	1	2	4	
20	42052601	Roller Assy.-Hopping	1	3	6	12	
21	42368501	Motor-Fan (60)PowL	1	1	2	4	SA9-1016
22	4PB4013-3100P006	Cup Screw A	2	1	2	4	
23	42423301	Plate-Patch	2	1	2	4	SA9-0926
24	42104603	Tape AL Film	1	-	-	-	L=35mm SA9-0980
25	NK2-16SUS	Pin	1	-	-	-	
26	2233013P0100	Connector (9715B-10Z02)	1	2	4	8	2nd Tray




Figure 7-11 Eject\_Assy

Table 7-11

## Guide\_Assy-Eject-L

No.	Parts No.	Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks
				per 500	per 1000	per 2000	
1	42063201	Guide-Eject-Lower	1	2	4	8	
2	42278501	Post-Gear-Idle-Heat	1	1	2	4	
3	42063801	Gear-Idle-Exit (Z33)	1	2	4	8	
4	42221001	Post-G.E.L.-Z33	1	1	2	4	
5	42063301	Lever-Eject-Sensor	1	2	4	8	
6	40386501	Spring-SNS (F/R)	1	1	2	4	
7	40135301	Photo-Interrupter	1	1	2	4	
8	42141101	CONN Cord-AMP3P-AMP3P	1	2	4	8	RSM-Exit
9	42142001	CONN Cord-AMP4P-AMP4P	1	2	4	8	RSM-Fuse
10	42142101	CONN Cord-AMP2P-JST3P	1	2	4	8	Fuse-Low Vol
11	42063601	Spring-FG	1	1	2	4	
12	3263124K0107	GS1/2A100MWK-T52 RES-MET solid - Q	1	1	2	4	
13	42141702	CONN Cord-JST4P-JST4P	1	2	4	8	PU-Heater Motor
14	42059401	Guide-Cable-R	1	1	2	4	
15	42064401	Guide-Eject-Upper	1	1	2	4	
16	42308001	Shaft Assy-Eject (FU)	1	1	2	4	
17	42308101	Shaft Assy-Eject (FD)	1	1	2	4	
18	42064501	Gear-Idle-Exit (Z58)	1	1	2	4	
19	42064701	Gear-Idle-Exit (Z41)	1	1	2	4	
20	42278301	Roller-Sub-G.E.U.	2	1	2	4	
21	42064301	Guide-Assy-Eject-U	1	2	4	8	
22	42063101	Guide-Assy-Eject-L	1	2	4	8	

## APPENDIX A INTERFACE SPECIFICATIONS

### 1. Parallel Interface Specifications (C5300)


#### 1.1 Parallel Interface

Item	Description
Mode	Compatibility mode, Nibble mode, ECP mode
Data bit length	8 bits: Compatibility mode, 4bits: Nibble mode,9 bits: ECP mode

#### 1.2 Parallel Interface Connector and Cable

##### 1) Connector

- Printer side: 36-pin receptacle  
Type 57LE-40360-12 (D56) (made by Daiichi Denshi) or equivalent
- Cable side: 36-pin plug  
Type 57FE-30360-20N (D8) (made by Daiichi Denshi) or equivalent



Connector Pin Arrangement Viewed from Cable Side

##### 2) Cable

- Cable length: 1.8 m max.  
(A shielded cable composed of twisted pair wires is recommended for noise prevention.)


#### 1.3 Parallel Interface Level

- LOW: 0 V to +0.8 V
- HIGH: +2.4 V to 5.0 V


1.4 Timing Charts

Compatible mode


a) Data receiving timing




b) On-line (off-line switching timing by ON-LINE SW)



c) Off-line (on-line switching timing by ON-LINE SW)



d) nlnit timing (invalid by default)



## 1.5 Parallel I/F Signals

Table 8-1 shows interface signal names and pin numbers.

Table 8-1 Signals

Pin No.	Signal Name	Signal Direction	Functions
1	Nstrobe (HostClk)	→PR	Pulse for reading data in at trailing edge.
2	DATA 1		
3	DATA 2		
4	DATA 3		8-bit parallel data.
5	DATA 4	→PR	Each signal is HIGH when data is logical 1 and
6	DATA 5		LOW when it is logical 0.
7	DATA 6		
8	DATA 7		
9	DATA 8		
10	nAck (PtrClk)	←PR	Indicates the completion of data reception.
11	Busy (PtrBusy)	←PR	Indicates whether the printer is ready for receiving data. Data cannot be received while the signal is HIGH.
12	PError (AckDataReq)	←PR	Indicates paper error when held HIGH.
13	Select (Xflag)	←PR	HIGH without exception when the parallel interface is enabled.
14	NAutoFd (HostBusy)	→PR	Used in bidirectional communication.
15	-	-	Unassigned.
16	GND	-	Signal ground.
17	FG	-	Chassis ground.
18	+5V	←PR	Used for supplying +5V. Power cannot be supplied to the outside of the printer.
19			
~	GND	-	Signal ground.
30			
31	Ninit (nInit)	→PR	Initializes the printer when held LOW.
32	NFault (nDataAvail)	←PR	LOW during alarm.
33	GND	-	Signal ground.
34	-	-	Unassigned.
35	HILEVEL	←PR	Pulled up to +5V at 3.3KΩ inside the printer.
36	Nselectin (IEEE 1284 active)	→PR	Used in bidirectional communication. Low without exception in compatible mode.

**Note:** Parenthesized signal names are used in nibble mode.

Only functions in compatible mode are listed.

This printer supports the IEEE std 1284-1994 nibble mode. Note that, when used with personal computers or cables that do not comply with the standards, the printers may exhibit unpredictable behavior.

## 2. Universal Serial Bus (USB) Interface Specifications


### 2.1 USB Interface

- (1) Basic specifications  
Conforms to USB specification, revision 1.1.
- (2) Transmission mode  
Full speed (max. 12 Mbps + 0.25%)
- (3) Power Control  
Self-power device

### 2.2 USB Interface Connector and Cable

- (1) Connector  
Printer side: Type B receptacle  
Upstream port  
UBB-4R-D14T-1 (made by JST) or equivalent

Connector pin layout



Cable side: Type B plug

- (2) Cable  
Cable length: 5 m max. (cable compliant with USB specification, revision 1.1)  
(A shielded cable must be used.)

### 2.3 USB Interface Signals

	R1	Function
1	Vbus	Power Supply (+5V) (red)
2	D -	Data transmission (white)
3	D +	Data transmission (green)
4	GND	Signal ground (black)
Shell	Shield	

### 3 Network Interface Specifications

#### 3.1 Network Interface

(1) Basic specifications

Network protocol

TCP/IP Specification

Network layer

ARP, RARP, IP, ICMP

Transport layer

TCP, UDP

Application layer


LPR, FTP, TELNET, HTTP, BOOTP, SMTP

#### 3.2 Network Interface Connector and Cable

(1) Connector

100 BASE-TX / 10 BASE-T

Connector pin layout



(2) Cable

RJ-45 anti-Shield twist pair cable with connector (Category 5 recommended)

#### 3.3 Network Interface Signals


Pin No.	Signals	Signal Direction	Functions
1	TXD+	FROM PRINTER	Send Data +
2	TXD-	FROM PRINTER	Send Data -
3	RXD+	TO PRINTER	Received Data +
4	-	-	Unassigned
5	-	-	Unassigned
6	RXD-	TO PRINTER	Received Data -
7	-	-	Unassigned
8	-	-	Unassigned

## APPENDIX B 2ND TRAY MAINTENANCE

### 1. Parts Replacement


#### 1.1 PCB

- (1) Unscrew the six screws ① to remove the plate-top ②.
- (2) Remove the cover-side R ③.
- (3) Remove the connectors (at five places), then uninstall the board ④.
- (4) Remove the cover - 2nd tray ⑤.




## 1.2 Frame Assy- Hopping

- (1) Remove the PCB (see section 1.1).
- (2) Remove the three screws ① to uninstall the hopping assy ②.
- (3) Unscrew the two screws ③ to remove the cover assy - front ④.
- (4) Unscrew the two screws ⑤ to remove the motor ⑥.
- (5) Remove the E ring ⑦ to remove the clutch ⑧.
- (6) Remove the roller assy - hopping ⑨.
- (7) Remove the roller assy - feed ⑩.



## 2. PARTS LIST




No.	Parts No.	Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks
				per 500	per 1000	per 2000	
1	42158504	Second Tray Unit	1	-	-	-	Packed in box.
	42158501	Second Tray Unit (ODS)	1	-	-	-	Packed in box.
	42158502	Second Tray Unit (OEL)	1	-	-	-	Packed in box.
	42158503	Second Tray Unit (AOS)	1	-	-	-	Packed in box.
2	42139801	Cassette Assy	1	1	2	4	
3	42136601	Guide Assy-Cassette-L	1	1	2	4	
4	42136801	Guide Assy-Cassette-R	1	1	2	4	
5	42137101	Frame Assy-Hopping	1	2	4	8	
6	42052601	Roller Assy-Hopping	1	2	4	8	
7	40313201	Roller Assy-Feed	1	1	2	4	
8	41400001	Shaft-Roller	1	1	2	4	
9	42138601	Cover-Assy-Front	1	2	4	8	
10	41438401	Frame-Separation Assy	1	2	4	8	SA2-0088
11	41439401	Spring-Separation	2	2	4	8	
12	42058201	Motor-Registration	1	2	4	8	
13	42197702	Feeder Cluch	1	2	4	8	
14	41780308	Board-V7X	1	3	6	12	
15	40135301	Photo Interrupter	3	2	4	8	
16	2233014P0100	Connector-Plug	1	1	2	4	V7X-Plug
17	42142201	Connection Cord	1	1	2	4	V7X-P-End
18	42141102	Connection Cord	1	1	2	4	V7X-Motor
19	42141704	Connection Cord	1	1	2	4	SA2-0072
20	42142802	Connection Cord	1	1	2	4	V7X-Paper Loading and 1st-Tray SNS
21	42145401	Cover-2nd Tray	1	1	2	4	
22	1051010C0001	Core	1	1	2	4	SA2-0087

## APPENDIX C DUPLEX UNIT MAINTENANCE

### 1. Parts Replacement


#### 1.1 Duplex Unit

- (1) Slide out the duplex unit ①.




## 1.2 Upper Assy / Rear Assy

- (1) Remove the duplex unit (see section 2.2.20).
- (2) Warming the upper assy ①, detach it.
- (3) Warming the rear assy ②, detach it.




### 1.3 Duplex Transport Assy

- (1) Turn over the duplex transport assy.
- (2) Unscrew the three screws ① to remove the plate ②.
- (3) Make connector removal and claw disengagement to remove the PCB-V7X ③.
- (4) Disengage and remove the cover ④.
- (5) Unscrew the screw ⑤ to remove the motor assy ⑥.
- (6) Remove the gear ⑦ and the bushing ⑧ to remove the roller ⑨. Then the earth ⑩ and the bushing ⑪ become detached.
- (7) Remove the pulleys ⑫. The mini-pitch belts ⑬ become detached together with the pulley.
- (8) Remove the holders ⑭ and the bushings ⑮ to remove the rollers ⑯. The earth spring becomes detached together with each roller.
- (9) Remove the fan ⑰.
- (10) Remove the spring ⑱ to remove the solenoid ⑲.
- (11) Release claw engagement to remove the solenoid ⑳.
- (12) Remove the lever ㉑. The lever ㉒ and the spring ㉓ become detached together with the lever ㉑.
- (13) Remove the actuators ㉔ and ㉕.
- (14) Remove cable connection and then, by claw warping, detach the five transport sensors ㉖.
- (15) Unscrew the screw ㉗ to remove the lock lever ㉘. Then the spring becomes detached.



## 2. PARTS LIST



No.	Parts No.	Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks
				per 500	per 1000	per 2000	
1	42160301	Frame-Assy-Upper	1	1	2	4	
2	42160401	Frame-Assy-Lower	1	1	2	4	
3	42160501	Frame-Assy-Rear	1	1	2	4	
4	40135301	Photo-Interrupter	5	1	2	4	
5	42194801	Roller-Feed (H)	3	1	2	4	
6	41780309	Board-V7X	1	2	4	8	
7	42058302	Solenoid	1	1	2	4	
8	42396201	Motor-Fan	1	1	2	4	
9	42160601	Gear-Assy	1	1	2	4	
10	42162001	Gear-Assy-Clutch	1	2	4	8	
11	42058201	Motor-Regist	1	1	2	4	
12	2233014P0110	Connector-Plug	1	1	2	4	
13	42142601	Connection-Cord	1	1	2	4	V7X-Plug
14	42142801	Connection-Cord	1	1	2	4	V7X-Front and Rear SNS
15	42142701	Connection-Cord	1	1	2	4	V7X-In and Cover SNS
16	42141104	Connection-Cord	1	1	2	4	V7X-Bottom SNS
17	42141705	Connection-Cord	1	1	2	4	V7X-Motor
18	42194701	Roller-Feed (Rv)	1	1	2	4	